



Manufactured by:
Backyard Discovery
3305 Airport Drive, Pittsburg, KS 66762
800-856-4445

Basepoint Business Centre: Rivermead Drive, Westlea, Swindon SN5 7EX Phone: 0800-118-2476 J.P. Coenstraat 7, The Bridge, The Hague, 2595 WP, Netherlands Phone: 08005678990

16x12 STRATFORD, ASHFORD, HAWTHORNE PERGOLA

Models #'s : 2105027B, 2105034B, 2105041B

The assembly manual must be retained
since it contains important information



WARNING

Cancer and Reproductive Harm
www.P65Warnings.ca.gov



2105027B
STRATFORD (BLACK)



2105034B
ASHFORD (BROWN)



Electrical enclosure available
only in North America



2105041 HAWTHORNE
(WHITE)

Please visit www.backyarddiscovery.com

For the most up to date assembly manual, to register your product, or to order
replacement parts *Para obtener instrucciones en español, visite*
www.backyarddiscovery.com



EASY STEP-BY-STEP
3D INTERACTIVE INSTRUCTIONS
DOWNLOAD THE FREE APP

ONLY AVAILABLE IN NORTH AMERICA



INSTALLATION
SERVICES
AVAILABLE!*
See inside for details
ONLY AVAILABLE IN U.S.



It is critically important that you start with square and level footings, concrete pad or deck to attach your structure

- Pay close attention to the items needed for each step. Make sure you are using the correct hardware for each step. Using incorrect hardware may result in improper assembly
- Remember to double check for underground utilities and overhead electrical lines




Post mounts are provided with your structure which allows you to permanently install your structure to a pre-existing or new wood or concrete surface.

- The hardware to attach the post mounts to the structure is included.
- The hardware to mount the structure permanently to a concrete surface is NOT included.
- The hardware to mount the structure permanently to a wood deck is NOT included and will need to be purchased separately. **You must ensure there is ample structural support under the deck before permanently attaching.**

Metal Roof Assembly


Remove plastic covering from metal roof panels before installing each piece. Place roofing materials on a nonabrasive, flat surface before and after assembly as it could bend, dent or scratch

Overall Dimensions






Metal Components (Not to Scale)



A1 POST - A4M01565
(2) 6"x6"x88" (152x152x2235)



A2 POST - A4M01566
(2) 6"x6"x88" (152x152x2235)



B1 JOIST END - A4M01610
(2) 1 3/8"x5 1/4"x60 1/2" (36x134x1537)



B2 JOIST END - A4M01611
(2) 1 3/8"x5 1/4"x60 1/2" (36x134x1537)



B3 JOIST - A4M01596
(2) 1 3/8"x5 1/4"x71 1/4" (36x134x1811)



C1 JOIST END - A4M01612
(2) 1 3/8"x5 1/4"x72 1/8" (36x134x1831)




C2 JOIST END - A4M01613
(2) 1 3/8"x5 1/4"x72 1/8" (36x134x1831)




D1 JOIST END - A4M01614
(8) 1 5/8"x3 1/8"x72 1/8" (40x80x1831)



D2 JOIST END - A4M01615
(24) 1 5/8"x3 1/8"x72 1/8" (40x80x1831)




Metal Components (Not to Scale)



J1 SPLICE BRACKET - A4M01269
(4) 1 1/4"x5 1/8"x19 5/8" (33x131x500)



J2 SPLICE BRACKET - A4M01270
(2) 1 1/4"x5 1/8"x15 3/4" (33x131x400)




J3 SPLICE BRACKET - A4M01271
(16) 1 1/2"x3"x15 3/4" (37x77x400)




E1 PURLIN END - A4M01272
(24) 3/4"x1 5/8"x65 3/4" (20x40x1670)




E2 PURLIN - A4M01277
(12) 3/4"x1 5/8"x60 3/8" (20x40x1534)




F1 LONG ANGLE BRACE - A4M01273
(2) 1 1/8"x4"x21 1/2" (30x101x546)




F2 LONG ANGLE BRACE - A4M01274
(2) 1 1/8"x4"x21 1/2" (30x101x546)




F3 SHORT ANGLE BRACE - A4M01275
(2) 1 1/8"x4"x14" (30x101x355)




F4 SHORT ANGLE BRACE - A4M01276
(2) 1 1/8"x4"x14" (30x101x355)




Hardware Components



H101101 | TORX PAN HEAD
(242) | 1/4-20x3/4"



H101053 | STEEL WASHER
(322) | 6x20



H101054 | SEALANT WASHER
(322)




H101107 | TORX PAN HEAD
(50) | 1/4-20x1 1/2"




H101102 | TORX PAN HEAD
(34) | 1/4-20x4"




H101103 | TORX SOCKET SCREW
(34) | 1/4-20




H100114 | TORX WRENCH
(2) | T-30




H100147 | TORX BIT
(2) | T-30




Accessory Components (Not to Scale)




G1 POST FOOT PLATE - A4M01278
(4) 2 1/8" x 8 3/8" x 8 3/8" (54x213x213)




G2 POST FOOT - A4M01279
(4) 2 5/8" x 9 7/8" x 9 7/8" (68x250x250)



G3 FOOT PLASTIC PLATE - A6P00464
(4) 3/8" x 8 1/8" x 8 1/8" (11x207x207)



H1 HOLE COVER - A4M01352
(32)



H2 2-WAY SQUARE PLUG- A6P00465
(24) 3/4" x 1 5/8" x 2" (20x40x52)



9205413 ELECTRICAL ENCLOSURE
(x1)

PRE-ASSEMBLY STEP 1


SORTING PARTS



ASSEMBLY TIP:

Keep an eye out for these boxes which will contain helpful pictures and information making the assembly process as quick and painless as possible.


Sorting Parts




When removing the parts from the boxes we recommend arranging them by part number before you begin assembly. This will allow for faster assembly and easily identify any parts that may be missing or damaged.

Hardware is identified with a seven digit alpha-numeric part number. During assembly you only need to reference the last three digits of the part number as noted in each step. This will make finding the correct hardware easier.

Hardware Identification




053 (x4)
STEEL WASHER - 6x20
054 (x4)
RUBBER WASHER - 6x20



Tools Required



Some steps in the assembly process will require a second set of hands. Make sure you have a helper available.



You will need to make sure that your assembly is square before fully tightening your bolts.



For proper assembly you will need to ensure that your structure is level before proceeding to the next step.



A tape measure may be needed to check overall dimensions to ensure structure is square.



A ladder will be needed for assembly. DO NOT stand or climb on any part of the structure at any point. Doing so may result in injury.



PRE-ASSEMBLY STEP 2

CHOOSE YOUR ASSEMBLY METHOD

There are several types of assembly instructions available to you.

1. Printed Assembly Manual included with your set
2. BILT APP - 3D interactive instructions
3. Combination of the Printed Manual and BILT APP (Note: Step numbers can differ between the two methods)





PERGOLA ASSEMBLY


STEP 1



C1 JOIST END - A4M01612
(2) 1 3/8" x 5 1/4" x 72 1/8" (36x134x1831)



J2 SPLICE BRACKET - A4M01270
(2) 1 1/4" x 5 1/8" x 15 3/4" (33x131x400)



F3 SHORT ANGLE BRACE - A4M01275
(2) 1 1/8" x 4" x 14" (30x101x355)



H101101 TORX PAN HEAD BOLT - 1/4-20x3/4"
(16)



H101053 STEEL WASHER 6x20
(16)



H101054 SEALANT WASHER
(16)

 **DO NOT FULLY TIGHTEN BOLTS AT THIS STEP.**

**J2 (x1)
SPLICE BRACKET**

**C1 (x1)
JOIST END**


**101 (x8)
BOLT - 3/4"**

**F3 (x1)
SHORT ANGLE BRACE**

J2 SLIDES INTO C1. LINE UP THREE HOLES ON J2 WITH THREE HOLES ON C1 AND INSERT BOLTS TOP AND BOTTOM.

**053 (x8)
STEEL WASHER - 6x20**

**054 (x8)
SEALANT WASHER**




COMPLETE THIS STEP TWICE.



PERGOLA ASSEMBLY

STEP 2



C2 JOIST END - A4M01613
(2) 1 3/8" x 5 1/4" x 72 1/8" (36x134x1831)



F4 SHORT ANGLE BRACE - A4M01276
(2) 1 1/8" x 4" x 14" (30x101x355)



H101101 TORX PAN HEAD
(16) 1/4-20x3/4"




H101053 STEEL WASHER
(16) 6x20



H101054 SEALANT WASHER
(16)

SLIDE C2 ONTO SPLICE BRACKET. STAND UP ASSEMBLY ON END WITH PACKAGING CARDBOARD ON GROUND. TAP UNTIL GAP IS GONE THEN TIGHTEN ALL BOLTS ON JOIST.



COMPLETE THIS STEP TWICE.




PERGOLA ASSEMBLY

STEP 3

A1 POST - A4M01565
(2) 6"x6"x88" (152x152x2235)

A2 POST - A4M01566
(2) 6"x6"x88" (152x152x2235)



H101101 TORX PAN HEAD
(8) 1/4-20x3/4"



H101053 STEEL WASHER
(8) 6x20




H101103 TORX SOCKET SCREW
(16) 1/4x20



H101054 SEALANT WASHER
(8)




LAY PARTS ON GROUND OR SAW HORSES FOR EASE OF ASSEMBLY.



103 (x8)
BOLT - 1/4x20

ENSURE UPPER BOLT HOLES
ARE FACING OUT ON POSTS.




REPEAT THIS STEP FOR OTHER UPRIGHT ASSEMBLY.




PERGOLA ASSEMBLY

STEP 4



G1 | **POST FOOT PLATE - A4M01278**
(4) | 2 1/8" x 8 3/8" x 8 3/8" (54x213x213)



G2 | **POST FOOT - A4M01279**
(4) | 2 5/8" x 9 7/8" x 9 7/8" (68x250x250)



H101101 | **TORX PAN HEAD**
(8) | 1/4-20x3/4"




H101053 | **STEEL WASHER**
(8) | 6x20



H101054 | **SEALANT WASHER**
(8)



SLIDE A POST FOOT ONTO EACH POST THEN BOLT ON POST FOOT PLATES TO EACH POST. VERTICAL TAB ON POST FOOT PLATE LINES UP WITH HOLES ON SIDE OF POST.



REPEAT THIS STEP FOR OTHER UPRIGHT ASSEMBLY.



B3 JOIST - A4M01596
(2) 1 3/8"x5 1/4"x71 1/4" (36x134x1811)

J1 SPLICE BRACKET - A4M01269
(4) 1 1/4"x5 1/8"x19 5/8" (33x131x500)

H101101 (24) TORX PAN HEAD 1/4-20x3/4"



H101053 (24) STEEL WASHER 6x20

H101054 (24) SEALANT WASHER



DO NOT FULLY TIGHTEN BOLTS AT THIS STEP.

DO NOT INSERT A BOLT INTO THE LARGER HOLE ON EITHER END.



REPEAT THIS STEP FOR OTHER JOIST.



PERGOLA ASSEMBLY

STEP 6



B1 JOIST END - A4M01610
(2) 1 3/8"x5 1/4"x60 1/2" (36x134x1537)



B2 JOIST END - A4M01611
(2) 1 3/8"x5 1/4"x60 1/2" (36x134x1537)



F1 LONG ANGLE BRACE - A4M01273
(2) 1 1/8"x4"x21 1/2" (30x101x546)



F2 LONG ANGLE BRACE - A4M01274
(2) 1 1/8"x4"x21 1/2" (30x101x546)




H101101 (32) **TORX PAN HEAD** **H101053** **STEEL WASHER**
1/4-20x3/4"



H101054 (32) **SEALANT WASHER**

SLIDE B1 ONTO SPLICING BRACKET. STAND UP ASSEMBLY ON END WITH PACKAGING CARDBOARD ON GROUND. TAP UNTIL GAP IS GONE THEN TIGHTEN ALL BOLTS. REPEAT WITH B2.




DO NOT FULLY TIGHTEN BOLTS
ON ANGLE BRACES AT THIS STEP.

REPEAT THIS STEP FOR OTHER JOIST ASSEMBLY.



PERGOLA ASSEMBLY

STEP 7



(2) UPRIGHT ASSEMBLY - FROM PREVIOUS STEPS



(2) JOIST ASSEMBLY - FROM PREVIOUS STEPS



H101101 (8) TORX PAN HEAD 1/4-20x3/4"



H101103 (16) TORX SOCKET SCREW 1/4-20



H101053 (8) STEEL WASHER 6x20




H101054 (8) SEALANT WASHER

WITH BOTH UPRIGHT ASSEMBLIES STANDING, ONE JOIST ASSEMBLY IS BOLTED ON WITHOUT FULLY TIGHTENING BOLTS. ONCE ONE JOIST ASSEMBLY IS BOLTED ON, BOLT ON SECOND JOIST ASSEMBLY.


JOIST ASSEMBLY (x2)

UPRIGHT ASSEMBLY (x2)



SQUARE UP ALL POSTS TO JOIST ASSEMBLIES AND FULLY TIGHTEN ALL BOLTS.


NOTE: A THIRD PERSON IS HELPFUL FOR THIS STEP.



G3 | FOOT PLASTIC PLATE - A6P00464

(4) | 3/8"x8 1/8"x8 1/8" (11x207x207)

LIFT UP EACH POST AND SLIDE A FOOT PLASTIC PLATE UNDER EACH POST FOOT PLATE.



G3 (x4)
FOOT PLASTIC PLATE



PERGOLA ASSEMBLY

STEP 9

D1 JOIST END - A4M01614

(4) 1 5/8"x3 1/8"x72 1/8" (40x80x1831)


J3 SPLICE BRACKET - A4M01271

(4) 1 1/2"x3"x15 3/4" (37x77x400)


H101101 (16) TORX PAN HEAD
1/4-20x3/4"

H101053 (16) STEEL WASHER
6x20

H101054 (16) SEALANT WASHER



COMPLETE THIS STEP FOUR TIMES.



PERGOLA ASSEMBLY

STEP 10



D1 JOIST END - A4M01614
(4) 1 5/8"x3 1/8"x72 1/8" (40x80x1831)



H101101 TORX PAN HEAD
(16) 1/4-20x3/4"




H101053 STEEL WASHER
(16) 6x20



H101054 SEALANT WASHER
(16)

SLIDE D1 ONTO SPLICE BRACKET. STAND UP ASSEMBLY ON END WITH PACKAGING CARDBOARD ON GROUND. TAP UNTIL GAP IS GONE THEN TIGHTEN ALL BOLTS ON JOIST.



COMPLETE THIS STEP FOUR TIMES.



(4) JOIST ASSEMBLY - FROM PREVIOUS STEPS



H101102 | TORX PAN HEAD
(8) | 1/4-20x4"



H101053 | STEEL WASHER
(8) | 6x20




H101054 | SEALANT WASHER
(8)

BOLT ONE SIDE OF JOISTS FIRST THEN BOLT OTHER SIDE. DO NOT FULLY TIGHTEN BOLTS AT THIS STEP.



JOIST ASSEMBLY (x4)



053 (x8)
STEEL WASHER - 6x20
054 (x8)
SEALANT WASHER

ENSURE JOIST ASSEMBLIES ARE SPACED OUT CORRECTLY AS PLACEMENT IS CRITICAL FOR PURFLIN ATTACHMENT.




D2 JOIST END - A4M01615
(12) 1 5/8"x3 1/8"x72 1/8" (40x80x1831)

J3 SPLICE BRACKET - A4M01271
(12) 1 1/2"x3"x15 3/4" (37x77x400)


H101101 (48) TORX PAN HEAD
1/4-20x3/4"

H101053 (48) STEEL WASHER
6x20

H101054 (48) SEALANT WASHER



COMPLETE THIS STEP TWELVE TIMES.



D2 JOIST END - A4M01615
(12) 1 5/8" x 3 1/8" x 72 1/8" (40x80x1831)



H101101 TORX PAN HEAD
(48) 1/4-20x3/4"




H101053 STEEL WASHER
(48) 6x20



H101054 SEALANT WASHER
(48)

SLIDE D2 ONTO SPLICING BRACKET. STAND UP ASSEMBLY ON END WITH PACKAGING CARDBOARD ON GROUND. TAP UNTIL GAP IS GONE THEN TIGHTEN ALL BOLTS ON JOIST.



COMPLETE THIS STEP TWELVE TIMES.



PERGOLA ASSEMBLY

STEP 14

(12) JOIST ASSEMBLY - FROM PREVIOUS STEPS



H101102 | TORX PAN HEAD
(24) | 1/4-20x4"




H101053 | STEEL WASHER
(24) | 6x20





H101054 | SEALANT WASHER
(24)

BOLT ONE SIDE OF JOISTS FIRST THEN BOLT OTHER SIDE. DO NOT FULLY TIGHTEN BOLTS YET.




JOIST ASSEMBLY (x12)






E2 | PURLIN - A4M01277
(12) | 3/4"x1 5/8"x60 3/8" (20x40x1534)



H2 | 2-WAY SQUARE PLUG- A6P00465
(24) | 3/4"x1 5/8"x2" (20x40x52)




SLIDE A 2-WAY SQUARE PLUG INTO EACH END OF PURLIN.




COMPLETE THIS STEP TWELVE TIMES.

NOTE: A RUBBER MALLET MAY BE HELPFUL TO GET THE 2-WAY SQUARE PLUGS INTO THE ENDS OF THE PURLIN.



PERGOLA ASSEMBLY

STEP 16



(12) PURLIN ASSEMBLY - FROM PREVIOUS STEPS





H101107 | TORX PAN HEAD
(24) | 1/4-20x1 1/2"



H101053 | STEEL WASHER
(24) | 6x20



H101054 | SEALANT WASHER
(24)





E1 PURLIN END - A4M01272
(24) 3/4"x1 5/8"x65 3/4" (20x40x1670)

H101107 (24) TORX PAN HEAD
1/4-20X1 1/2"

H101053 (24) STEEL WASHER
6x20

H101054 (24) SEALANT WASHER



NOTE: A RUBBER MALLET MAY BE HELPFUL TO GET
THE PURLIN ENDS ONTO THE 2-WAY SQUARE PLUGS.

E1 (x24)
PURLIN END

PURLIN ENDS SLIDE ONTO
2-WAY SQUARE PLUGS.

107 (x24)
BOLT - 1 1/2"


 BOLT ON ONE SIDE OF ALL PURLINS THEN
BOLT ON OTHER SIDE. CENTER ALL
PURLINS AND FULLY TIGHTEN ALL PURLIN
BOLTS ONCE THEY ARE CENTERED.

053 (x24)
STEEL WASHER - 6x20

054 (x24)
SEALANT WASHER



H1 | HOLE COVER - A4M01352
(32)




**H1 (x32)
HOLE COVER**

USE A SMALL PIECE OF WOOD TO TAP HOLE COVERS IN WITH A RUBBER MALLET.



ELECTRICAL ENCLOSURE



FOR ELECTRICAL ENCLOSURE INSTALLATION REFER TO ASSEMBLY INSTRUCTIONS THAT COMES PACKAGED WITH THE ELECTRICAL ENCLOSURE KIT. INSTALL ON ANY POST THAT IS DESIRED. FOLLOW DIRECTIONS FOR PROPER INSTALLATION.