



Manufactured by:
Backyard Discovery
3305 Airport Drive, Pittsburg, KS 66762
800-856-4445

Basepoint Business Centre: Rivermead Drive, Westlea, Swindon SN5 7EX Phone: 0800-118-2476
J.P. Coenstraat 7, The Bridge, The Hague, 2595 WP, Netherlands Phone: 08005678990

18x10 EVANSTON STEEL WALL-MOUNTED LOUVERED PERGOLA

MODEL #: 2407138



WARNING

Cancer and Reproductive Harm
www.P65Warnings.ca.gov



Please visit www.backyarddiscovery.com
For the most up to date assembly manual, to register your product, or to order
replacement parts Para obtener instrucciones en español, visite
www.backyarddiscovery.com



EASY STEP-BY-STEP
3D INTERACTIVE INSTRUCTIONS
DOWNLOAD THE FREE APP







OWNER'S MANUAL - BASIC SETUP DIMENSIONS & ASSEMBLY NOTES

It is critically important that you start with square and level footings, concrete pad or deck to attach your structure.


- Pay close attention to the items needed for each step. Make sure you are using the correct hardware for each step. Using incorrect hardware may result in improper assembly
- Remember to double check for underground utilities and overhead electrical lines

Post mounts are provided with your structure which allows you to permanently install your structure to a pre-existing or new wood or concrete surface. See Anchor Instructions for further details and recommendations.

- The hardware to attach the post mounts to the structure is included.
 - The hardware to mount the structure permanently to a concrete surface is included.
 - The hardware to attach the structure permanently to a house is included.
 - The hardware to mount the structure permanently to a wood deck is NOT included and will need to be purchased separately. You must ensure there is ample structural support under the deck before permanently attaching.
-



OWNER'S MANUAL - ANCHORING LAYOUT




NOTE: DIMENSIONS ARE TO ANCHOR PLATE ON BOTTOM OF POST EXCEPT WHERE NOTED.

OWNER'S MANUAL - PARTS IDENTIFICATION

METAL COMPONENTS (NOT TO SCALE)



B01 BEAM - A4M03480
(x1) 1 7/16"x5 1/4"x114 7/8" (36x134x2918)



B02 BEAM - A4M03479
(x1) 1 7/16"x5 1/4"x114 7/8" (36x134x2918)



B03 BEAM - A4M04141
(x1) 1 7/16"x5 1/4"x103 7/8" (36x134x2639)




B04 BEAM - A4M04048
(x1) 1 7/16"x5 1/4"x103 7/8" (36x134x2639)




B05 BEAM - A4M04140
(x1) 1 7/16"x5 1/4"x103 7/8" (36x1/16"x2639)




B06 BEAM - A4M04142
(x1) 1 7/16"x5 1/4"x103 7/8" (36x134x2639)




F02 LOUVER STRAP - A4M04057
(x4) 1/8"x13/16"x101 3/4" (3x20x2585)



F01 FLAT BAR - A4M04056
(x2) 1/16"x1"x99 9/16" (2x25x2528)




G03 GUTTER - A4M04051
(x1) 1 9/16"x1 15/16"x99 5/8" (40x50x2530)



G01 GUTTER - A4M03478
(x1) 1 9/16"x1 15/16"x111 13/16" (40x50x2839)




G02 GUTTER - A4M04052
(x1) 1 9/16"x1 15/16"x99 5/8" (40x50x2530)



G05 GUTTER SPLICE - A4M02004
(x1) 1 7/16"x2 1/16"x3 15/16" (36x52.5x100)

OWNER'S MANUAL - PARTS IDENTIFICATION

METAL COMPONENTS (NOT TO SCALE)



G06 GUTTER - A4M03481
(x1) 1 9/16"x1 15/16"x111 13/16" (40x50x2839)




H01 HANDLE - A4M04022
(x1)




J1 SPLICE BRACKET - A4M02230
(x1) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)




K1 WEATHER STRIP - A6P01200
(x1) 1/16"x3 15/16"x199 9/16" (1.6x100x5068)




K03 CENTER WALL BRACKET - A4M03482
(x2) 2 11/16"x5 3/16"x6" (69x131x152)




K04 CORNER WALL BRACKET - A4M03483
(x2) 3 15/16"x5 1/8"x6" (99x131x152)




M02 LOUVER MOUNT - A4M04054
(x1) 1"x1 15/16"x99 1/2" (25x49x2528)




L01 LOUVER - A4M04137
(x30) 1 11/16"x7 3/4"x114 5/16" (42x196x2904)




M04 LOUVER MOUNT - A4M04053
(x1) 1"x1 15/16"x (25x49x2528)



M03 LOUVER MOUNT - A4M04055
(x2) 1"x1 15/16"x99 1/2" (25x49x2528)




P03 POST - A4M02131
(x1) 4 5/16"x6 3/4"x99 1/2" (110x172x2527)




P02 POST - A4M01984
(x1) 4 5/16"x6 3/4"x99 1/2" (110x172x2527)

OWNER'S MANUAL - PARTS IDENTIFICATION


METAL COMPONENTS (NOT TO SCALE)




F03 LINKAGE STRAP - A4M02229
(x1) 1/2"x11/16"x3 13/16" (13x17x97)




F04 LINKAGE STRAP - A4M02225
(x1) 1/8"x13/16"x2 5/8" (3x20x66)




F05 LOUVER DRIVE AXLE - A4M02226
(x1) 1/2"x1/2"x3 3/4" (13.0x13.0x95)




F06 SPACER - A4M02227
(x1) 1/16"x2 3/16"x2 3/4" (1.5x56x70)




F07 COVER - A4M02228
(x1) 1 9/16"x2 7/8"x3 1/4" (39.5x73x82)




CB01 POST BRACKET - A4M04063
(x2) 2 15/16"x2 15/16"x5 1/4" (74.5x74.5x134)




L03 LOUVER SIDE PLATE - A4M04138
(x59) 1/16"x2 3/16"x6 9/16" (2x55x167)




L02 LOUVER DRIVE SIDE PLATE - A4M04139
(x1) 1/16"x2 3/16"x6 9/16" (2x55x167)




L04 LOUVER MECHANISM - A4M02132
(x1)



9205413 ELECTRICAL ENCLOSURE
(x1)



A4M04024 SHIM
(x4)



A6P00796 SILICONE
(x1)




T01 TEMPLATE - W4L20947
(x2) 1/8"x5 1/2"x61 7/8" (3x140x1571)




T02 TEMPLATE - W4L20948
(x1) 1/8"x5 1/2"x86 1/16" (3x140x2186)

OWNER'S MANUAL - PARTS IDENTIFICATION


Hardware Components




H101202 TORX PAN HEAD 1/4-20x3/4 ASSY
(x136) 1/4-20x3/4 ASSY




H100497 WASHER FLAT BLK
(x12) 17x30




H101316 WASHER FLAT B LK
(x10) 8.5X30




H100630 WASHER FLAT BLK
(x8) 8x19




H101189 LOW PROFILE SHOULDER BOLT BLK
(x2) 1/4-20x3/8




H100474 WASHER FLAT BLK
(x5) 9x18




H100774 WASHER SPLIT BLK
(x1) 1/4



H100477 WASHER SPLIT BLK
(x10) 5/16




H101187 BOLT PPH BLK
(x1) 8-32x1 1/8




H100653 NUT LOCK BLK
(x2) 1/4




H101101 TORX PAN HEAD BLK
(x1) 1/4-20x3/4"




H101126 TORX PAN HEAD BLK
(x4) 1/4-20x2 1/8"




H100408 SCREW PWH BLK
(x120) 8x1/2




H101161 COTTER PIN
(x60)



H100481 BOLT HEX BLK
(x10) 5/16x1 1/4




H101165 CONCRETE ANCHOR 3/8"x3" BLK
(x12) 3/8x3




H101305 CONCRETE ANCHOR 1/4"x3"
(x8) 1/4x3



H101310 LAG HEX BLK
(x12) 3/8x3



H101313 EXPANSION ANCHOR
(x12)




H101311 PLASTIC ANCHOR
(x12) 3/8x3




H101230 BOLT WH S.S.
(x8) 5/16x6

OWNER'S MANUAL - PARTS IDENTIFICATION


Hardware Components




H101100 MAGNETIC DRIVER
(x1)




H100114 TORX WRENCH
(x1) T-30



H100147 TORX BIT
(x1) T-30



H101106 SOCKET DRIVER
(x1)



H101114 RIGHT ANGLE DRILL ADAPTER
(x1)


PRE-ASSEMBLY STEP 1 - SORTING PARTS

It is critical for ease of assembly that you take the time to sort and organize the parts and hardware.

METAL PARTS:

- Organize metal parts by the three-digit, alpha-numeric number stamped on each part (ex. P01).
- If there are multiple parts with the same stamped number, stack those pieces together.
- Stamps can be found on the flat surface of the parts or on the end of the parts.
- Allow yourself plenty of room - the parts can take up a significant amount of space.

**NOTE: CARTONS ARE NOT ORGANIZED BY PART NUMBER.
IT IS RECOMMENDED TO LEAVE LOUVER ASSEMBLIES IN BOX UNTIL NEEDED.**



HARDWARE PARTS:

- We recommend that you have a separate table to organize the hardware.
- Hardware bags are printed with a seven-digit, alpha-numeric part number.
- You can organize your hardware by part number or group by hardware type (e.g. bolts, nuts, etc.).
- During assembly you only need to reference the last four digits of the number.



PRE-ASSEMBLY STEP 2 - TOOLS REQUIRED



Cordless Drill or
Electric Drill




Drill Attachments:
Phillips Head



1/8", 3/16", 3/8" &
7/16" Drill Bits



Phillips Screw Driver



Open End Wrench
7/16"




3/8" Drive Ratchet, 1/2" &
7/16" STD Sockets 1/2" & 7/16"
Deep Sockets




Claw Hammer



Rubber Mallet -
Optional



Tape Measure



Square




Level 24"

PRE-ASSEMBLY STEP 3 - CHOOSE YOUR ASSEMBLY METHOD

There are several types of assembly instructions available to you.

1. Printed Assembly Manual included with your set
2. BILT APP - 3D interactive instructions
3. Combination of the Printed Manual and BILT APP (Note: Step numbers can differ between the two methods)




BILT.[®]

Scan for easy
3D instructions

Download the BILT app
before you begin

Download on the
App Store

GET IT ON
Google Play



Hardware Needed


17

< || >


The image is a promotional graphic for the BILT app. It features the BILT logo at the top left, a QR code at the top right, and the text 'Scan for easy 3D instructions' in a large, bold font. Below this, it says 'Download the BILT app before you begin'. There are two buttons for downloading the app: 'Download on the App Store' and 'GET IT ON Google Play'. At the bottom, there is a smartphone displaying a 3D assembly instruction interface. The interface shows a 3D model of a structure with a horizontal beam and a triangular support. The text 'Hardware Needed' is visible at the top of the app screen, and the number '17' is in the bottom left corner. Navigation icons like back, play/pause, and forward are at the bottom of the app screen.

OWNER'S MANUAL - WALL ATTACHMENT TYPES


Determine which wall attachment type works best for your application. If unknown consult a licensed contractor. The recommended hardware below is provided. Backyard Discovery does not assume responsibility for any damages to your house.




ATTACHING TO WALL WITH LAG SCREWS




ATTACHING TO WALL WITH LAGS USING PLASTIC ANCHORS



ATTACHING TO MASONRY WITH CONCRETE ANCHORS




ATTACHING TO MASONRY WITH CONCRETE ANCHORS USING PLASTIC ANCHORS




ATTACHING TO MASONRY WITH EXPANSION ANCHORS

STEP 1 - WALL BRACKET LOCATION LAYOUT


1. DRAW A STRAIGHT LINE 8'-0" (2438mm) OFF THE GROUND.




2. ALIGN THE BOTTOM OF T01 WITH THE STRAIGHT LINE AND KEEP IT LEVEL BY USING A 24" LEVEL.




3. DRAW 3 CIRCLES ACCORDING TO HOLES IN T01.



4. ALIGN T02 WITH T01 AND KEEP IT LEVEL BY USING A 24" LEVEL.



5. DRAW 6 CIRCLES ACCORDING TO HOLES IN T02.




6. ALIGN T01 WITH T02 AND KEEP IT LEVEL BY USING A 24" LEVEL.



7. DRAW 3 CIRCLES ACCORDING TO HOLES IN T01 .




8. DRILL INTO THE WALL AT THE CENTER OF EACH CIRCLE. DRILL SIZE DETAILS ARE OUTLINE IN STEP 2A-E, DEPENDING ON WHAT ANCHORS YOU ARE USING.




CRITICAL: ALL HOLES MUST BE LEVEL ACROSS THE 4 BRACKETS.

STEP 2A - WALL BRACKET INSTALLATION USING CONCRETE ANCHORS



K04 CORNER WALL BRACKET - A4M03483
(x2) 3 15/16"x5 1/8"x6" (99x131x152)




K03 CENTER WALL BRACKET - A4M03482
(x2) 2 11/16"x5 3/16"x6" (69x131x152)


Qty	PartNo	Description
12	H100497	WASHER FLAT 17x30 BLK
12	H101165	CONCRETE ANCHOR 3/8x3" BLK

- DRILL (12) 5/16" [8mm] HOLES IN THE WALL ACCORDING TO LAYOUT IN STEP 1.
- INSTALL WALL BRACKETS WITH CONCRETE ANCHORS.
- THE INSTALLATION HEIGHT OF WALL BRACKETS WILL BE A LITTLE HIGHER THAN THE HEIGHT OF P02 (POST), SO THE TOP HAS A SLIGHT ANGLE TO FACILITATE DRAINAGE.
- REPEAT THIS STEP TWO TIMES

BRACKET LAYOUT



K04





K03




K03




K04



STEP 2B - WALL BRACKET INSTALLATION USING CONCRETE ANCHORS WITH PLASTIC ANCHORS



K04 CORNER WALL BRACKET - A4M03483
(x2) 3 15/16"x5 1/8"x6" (99x131x152)




K03 CENTER WALL BRACKET - A4M03482
(x2) 2 11/16"x5 3/16"x6" (69x131x152)

Qty	PartNo	Description
12	H100497	WASHER FLAT 17x30 BLK
12	H101165	CONCRETE ANCHOR 3/8x3" BLK
12	H101311	PLASTIC ANCHOR 3/8x3

- DRILL (12) 1/2" [12mm] HOLES IN THE WALL ACCORDING TO LAYOUT IN STEP 1.
- INSTALL WALL BRACKETS WITH CONCRETE ANCHORS AND PLASTIC ANCHORS.
- THE INSTALLATION HEIGHT OF WALL BRACKETS WILL BE A LITTLE HIGHER THAN THE HEIGHT OF P02 (POST), SO THE TOP HAS A SLIGHT ANGLE TO FACILITATE DRAINAGE.
- REPEAT THIS STEP TWO TIMES

BRACKET LAYOUT



K04




K03



K03




K04




STEP 2C - WALL BRACKET INSTALLATION USING LAG SCREWS

Qty	PartNo	Description
12	H100497	WASHER FLAT 17x30 BLK
12	H101310	LAG BOLT HEX 3/8 X 3 BLK




K04 CORNER WALL BRACKET - A4M03483
(x2) 3 15/16"x5 1/8"x6" (99x131x152)



K03 CENTER WALL BRACKET - A4M03482
(x2) 2 11/16"x5 3/16"x6" (69x131x152)

- DRILL (12) 1/4" [7mm] HOLES IN THE WALL ACCORDING TO LAYOUT IN STEP 1.
- INSTALL WALL BRACKETS WITH LAG SCREWS.
- THE INSTALLATION HEIGHT OF WALL BRACKETS WILL BE A LITTLE HIGHER THAN THE HEIGHT OF P02 (POST), SO THE TOP HAS A SLIGHT ANGLE TO FACILITATE DRAINAGE.
- REPEAT THIS STEP TWO TIMES

BRACKET LAYOUT



K04





K03




K03




K04



STEP 2D - WALL BRACKET INSTALLATION USING LAG SCREWS WITH PLASTIC ANCHORS



K04 CORNER WALL BRACKET - A4M03483
(x2) 3 15/16"x5 1/8"x6" (99x131x152)



K03 CENTER WALL BRACKET - A4M03482
(x2) 2 11/16"x5 3/16"x6" (69x131x152)

Qty	PartNo	Description
12	H100497	WASHER FLAT 17x30 BLK
12	H101310	LAG BOLT HEX 3/8 X 3 BLK
12	H101311	PLASTIC ANCHOR 3/8x3

- DRILL (12) 1/2" [12mm] HOLES IN THE WALL ACCORDING TO LAYOUT IN STEP 1.
- INSTALL WALL BRACKETS WITH LAG SCREWS AND PLASTIC ANCHORS.
- THE INSTALLATION HEIGHT OF WALL BRACKETS WILL BE A LITTLE HIGHER THAN THE HEIGHT OF P02 (POST), SO THE TOP HAS A SLIGHT ANGLE TO FACILITATE DRAINAGE.
- REPEAT THIS STEP TWO TIMES

BRACKET LAYOUT



K04




K03




K03




K04



STEP 2E - WALL BRACKET INSTALLATION USING EXPANSION ANCHORS



K04 CORNER WALL BRACKET - A4M03483
(2x) 3 15/16"x5 1/8"x6" (99x131x152)




K03 CENTER WALL BRACKET - A4M03482
(2x) 2 11/16"x5 3/16"x6" (69x131x152)

Qty	PartNo	Description
12	H100497	WASHER FLAT 17x30 BLK
12	H101313	EXPANSION ANCHOR


- DRILL (12) 3/8" [10mm] HOLES IN THE WALL ACCORDING TO LAYOUT IN STEP 1.
- INSTALL WALL BRACKETS WITH EXPANSION BOLTS.

- THE INSTALLATION HEIGHT OF WALL BRACKETS WILL BE A LITTLE HIGHER THAN THE HEIGHT OF P02 (POST), SO THE TOP HAS A SLIGHT ANGLE TO FACILITATE DRAINAGE.
- REPEAT THIS STEP TWO TIMES

BRACKET LAYOUT



K04




K03



K03



K04



STEP 3A - REAR BEAM ASSEMBLY

Qty	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




B03 BEAM - A4M04141
(x1) 1 7/16"x5 1/4"x103 7/8" (36x134x2638)



J1 SPLICE BRACKET - A4M02230
(x1) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)

- FOR EASE OF ASSEMBLY, WE RECOMMEND USING SAWHORSES FOR STEPS 3A-7
- **HAND TIGHTEN ONLY.**




STEP 3B - REAR BEAM ASSEMBLY

Qty	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




B05 BEAM - A4M04140
(x1) 1 7/16"x5 1/4"x103 7/8" (36x1/16"x2638)

- SLIDE B05 ONTO SPLICE BRACKET. GENTLY TAP ENDS OF ASSEMBLY WITH RUBBER Mallet UNTIL GAP CLOSES, THEN TIGHTEN ALL BOLTS ON BEAM.
- **HAND TIGHTEN ONLY.**





STEP 4A - REAR BEAM ASSEMBLY

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




M03 LOUVER MOUNT - A4M04055
(x1) 1"x1 15/16"x99 1/2" (25x49x2528)

- HAND TIGHTEN ONLY.



STEP 4B - REAR BEAM ASSEMBLY

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



M04 LOUVER MOUNT - A4M04053
(x1) 1"x1 15/16"x (25x49x2528)

- HAND TIGHTEN ONLY.


**SMALL 1/16" [1-2mm] GAP
BETWEEN LOUVER MOUNTS**

**1202 (x6)
TORX PAN HEAD
1/4-20x3/4 ASSY**

**LOUVER MOUNT WILL FIT
AROUND THREADED INSERTS
IN BEAM**

**M04 (x1)
LOUVER MOUNT**

**REAR BEAM ASSEMBLY
STEP - 3B**




STEP 5 - REAR BEAM WEATHER STRIP

Qty	PartNo	Description
14	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY


K1 WEATHER STRIP - A6P01200
(x1) 1/16"x3 15/16"x199 1/2" (1.6x100x5068)

- ALIGN SCREW HOLES
- WEATHER STRIP WILL NEED TO BE STRETCHED TO ALIGN HOLES. THIS ENSURES A TIGHT SEAL.




STEP 6 - REAR BEAM POST BRACKET

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




CB01 POST BRACKET - A4M04063
(x2) 2 15/16"x2 15/16"x5 1/4" (74.5x74.5x134)

- HAND TIGHTEN ONLY.




STEP 7 - REAR BEAM ASSEMBLY

Qty	PartNo	Description
8	H100477	WASHER SPLIT 5/16 BLK
8	H100481	BOLT HEX 5/16x1 1/4 BLK
8	H101316	WASHER FLAT 8.5x30 BLK





- WITH THE HELP OF ANOTHER ADULT, ATTACH REAR BEAM ASSEMBLY TO WALL BRACKETS.
- ALIGN SCREW HOLES.
- **TIGHTEN ALL HARDWARE FROM PREVIOUS STEPS.**




STEP 8A - LEFT FRAME ASSEMBLY

Qty	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




- ATTACH B02 BEAM TO POST BRACKET ON POST P03.
- **HAND TIGHTEN ONLY.**



STEP 8B - LEFT FRAME ASSEMBLY

Qty	PartNo	Description
1	H100477	WASHER SPLIT 5/16 BLK
1	H100481	BOLT HEX 5/16x1 1/4 BLK
2	H101230	BOLT WH 5/16x6 S.S.
1	H101316	WASHER FLAT 8.5x30 BLK


- WITH AT LEAST TWO EXTRA PEOPLE, ATTACH B02 BEAM TO P03 POST AND CB01 POST BRACKET ON REAR BEAM.
- ALIGN SLOTS IN BEAM WITH THREADED INSERTS ON TOP PLATE. FLUSH ALL SIDES OF BEAM AND POST.
- HAND TIGHTEN ONLY.



STEP 8C - LEFT FRAME ASSEMBLY


Qty	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- HAND TIGHTEN ONLY.




STEP 9 - LEFT GUTTER ASSEMBLY

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



G01 GUTTER - A4M03478
(x1) 1 9/16"x1 15/16"x 111 13/16"(40x50x2839)

- WITH AN ADDITIONAL PERSON, ATTACH GUTTER TO BEAM.
- MAKE SURE ENDS OF GUTTER SIT ON TOP SURFACE OF EACH POST BRACKET.
- TIGHTEN ALL HARDWARE FROM PREVIOUS STEPS.




STEP 10A - RIGHT FRAME ASSEMBLY

Qty	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




B01 BEAM - A4M03480
(x1) 1 7/16"x5 1/4"x114 7/8" (36x134x2918)



P02 POST - A4M01984
(x1) 4 5/16"x6 3/4"x99 1/2" (110x172x2527)

- ATTACH B01 TO POST BRACKET ON POST P02.
- **HAND TIGHTEN ONLY.**



STEP 10B - RIGHT FRAME ASSEMBLY

Qty	PartNo	Description
1	H100477	WASHER SPLIT 5/16 BLK
1	H100481	BOLT HEX 5/16x1 1/4 BLK
2	H101230	BOLT WH 5/16x6 S.S.
1	H101316	WASHER FLAT 8.5x30 BLK

- WITH AT LEAST TWO EXTRA PEOPLE, ATTACH B01 BEAM TO P02 AND CB01 POST BRACKET ON REAR BEAM.
- ALIGN SLOTS IN BEAM WITH THREADED INSERTS ON TOP PLATE. FLUSH ALL SIDES OF BEAM AND POST.

- HAND TIGHTEN ONLY.

CB01
POST BRACKET

BRACKET WILL FIT
AROUND THREADED
INSERTS IN BEAM

1316 (x1)
WASHER FLAT 8.5x30

477 (x1)
WASHER - 5/16"

481 (x1)
BOLT - 1 1/4"

BOTTOM VIEW

LEFT END

1230 (x2)
BOLT - 6"

TWO SLOTS ON LEFT
END OF BEAM

B01
BEAM

P02
POST


FLUSH

TWO LITTLE SLOTS INDICATE
TOP SURFACE OF BEAM

STEP 10C - RIGHT FRAME ASSEMBLY


Qty	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- HAND TIGHTEN ONLY.




STEP 11 - RIGHT GUTTER ATTACHMENT

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



- WITH AN ADDITIONAL PERSON, ATTACH GUTTER TO BEAM.
- MAKE SURE ENDS OF GUTTER SIT ON TOP SURFACE OF EACH POST BRACKET.
- TIGHTEN ALL HARDWARE FROM PREVIOUS STEPS.



STEP 12 - FRONT BEAM ASSEMBLY

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




B06 BEAM - A4M04142
 (x1) 1 7/16"x5 1/4"x103 7/8" (36x134x2638)



J1 SPLICE BRACKET - A4M02230
 (x1) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)

- BEAM AND SPLICE MUST BE ORIENTED AS SHOWN BELOW.
 SLIDE J1 INTO B06 AND LINE UP THREE HOLES TOP AND BOTTOM.
- HAND TIGHTEN ONLY.




STEP 13 - FRONT BEAM ASSEMBLY

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




B04 BEAM - A4M04048
(x1) 1 7/16"x5 1/4"x103 7/8" (36x134x2639)

- SLIDE B04 ONTO SPLICE BRACKET.
- GENTLY TAP ENDS OF ASSEMBLY WITH RUBBER Mallet UNTIL GAP CLOSES, THEN TIGHTEN ALL BOLTS ON BEAM.




STEP 14A - FRONT FRAME ASSEMBLY

Qty	PartNo	Description
4	H101230	BOLT WH 5/16x6 S.S.



BEAM ASSEMBLY
STEP - 13


- WITH AT LEAST TWO EXTRA PEOPLE, ATTACH BEAM ASSEMBLY FROM PREVIOUS STEPS TO P02 AND P03 POST.
- ALIGN SLOTS IN BEAM WITH THREADED INSERTS ON TOP PLATE. FLUSH ALL SIDES OF BEAM AND POST.
- HAND TIGHTEN ONLY.



STEP 14B - FRONT FRAME ASSEMBLY



Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- TIGHTEN ALL HARDWARE FROM PREVIOUS STEPS.




STEP 15 - FRONT BEAM LOUVER MOUNT ATTACHMENT

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




STEP 16 - FRONT BEAM LOUVER MOUNT ATTACHMENT


Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY





M02 LOUVER MOUNT - A4M04054
(x1) 1"X1 15/16"X99 1/2" (25x49x2528)



STEP 17A - FRONT BEAM GUTTER ATTACHMENT




- MEASURE APPROXIMATELY 1/2" [13mm] FROM EACH END OF GUTTER SPLICE AND APPLY A FINE BEAD OF SILICONE.
- SLIDE BOTH G03 AND G04 GUTTERS INTO SPLICE, ALIGNING SLOTS (ENDS WILL ALMOST BE TOUCHING).
- WIPE OFF ANY EXCESS SILICONE USING A RAG OR PAPER TOWEL.
- GLOVES ARE RECOMMENDED WHEN APPLYING SILICONE.
- MAKE SURE SURFACE OF GUTTER SPLICE IS CLEAN, DRY, AND FREE OF ANY DIRT/DEBRIS.





STEP 17B - FRONT BEAM GUTTER ATTACHMENT

Qty	PartNo	Description
12	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



- WITH AT LEAST TWO PEOPLE ATTACH GUTTER ASSEMBLY FROM PREVIOUS STEP TO BEAM.
- MAKE SURE ENDS OF GUTTER SIT ON TOP SURFACE OF EACH POST BRACKET.




STEP 17C - FRONT BEAM GUTTER ATTACHMENT




A6P00796 SILICONE
(x1)

- APPLY A FINE BEAD OF SILICONE ALONG INSIDE SURFACE OF GUTTER WHERE TWO GUTTER PIECES MEET.
- SMOOTH SILICONE ALONG SEAM. WIPING EXCESS USING A RAG OR PAPER TOWEL.
- **GLOVES ARE RECOMMENDED WHEN APPLYING SILICONE.**
- **MAKE SURE SURFACE OF GUTTER IS CLEAN, DRY, AND FREE OF ANY DIRT/DEBRIS.**




**APPLY A FINE
BEAD OF SILICONE
ALONG INSIDE SEAM
OF GUTTER**



STEP 18 - SQUARE STRUCTURE

**CRITICAL: SQUARE ASSEMBLY BEFORE PROCEEDING TO NEXT STEPS.
ONCE SQUARE, MAKE SURE ALL HARDWARE HAS BEEN
TIGHTENED FROM PREVIOUS STEPS.**

MEASUREMENTS TAKE FROM OUTSIDE CORNER TO OUTSIDE CORNER OF STRUCTURE




STEP 19 - GUTTER SEALANT




A6P00796 SILICONE
(x1)

- APPLY A FINE BEAD OF SILICONE ALONG INSIDE SURFACE OF GUTTER WHERE GUTTER PIECES MEET POST.
- SMOOTH SILICONE, WIPING EXCESS USING A RAG OR PAPER TOWEL.

- GLOVES ARE RECOMMENDED WHEN APPLYING SILICONE.
- MAKE SURE SURFACE OF GUTTER IS CLEAN, DRY, AND FREE OF ANY DIRT/DEBRIS.
- REPEAT THIS STEP FOR ALL GUTTER ATTACHMENT POINTS AT EACH POST.





APPLY A FINE BEAD OF
SILICONE TO PREVENT WATER
FROM LEAKING




STEP 20 - DRIVE LOUVER INSTALLATION


Qty	PartNo	Description
4	H100408	SCREW PWH 8x1/2 BLK



- DO NOT OVERTIGHTEN SCREWS.
- FOR EASE OF ASSEMBLY, WE RECOMMEND USING SAWHORSES FOR THIS STEP




STEP 21 - LOUVER INSTALLATION




- ORIENTATION OF LOUVER WILL BE DETERMINED BY THE SIDE BEAM WITH FOUR THREADED INSERTS.
- PLACE DRIVE LOUVER FROM PREVIOUS STEP IN THE SECOND SET OF LOUVER MOUNT GROOVES. L02 DRIVE PLATE WILL BE ON THE SAME SIDE AS FOUR THREADED INSERTS IN BEAM.

PLACE DRIVE LOUVER ASSEMBLY IN THE SECOND SET OF LOUVER MOUNT GROOVES




L02 SIDE PLATE MUST BE ON THE SAME END AS THE FOUR THREADED INSERTS

L02 LOUVER DRIVE SIDE PLATE




DRIVE LOUVER ASSEMBLY
STEP - 20




STEP 22 - LOUVER ASSEMBLY

Qty	PartNo	Description
116	H100408	SCREW PWH 8x1/2 BLK




L01 LOUVER - A4M04137
(x29) 1 11/16"x7 3/4"x114 5/16" (42x196x2904)




L03 LOUVER SIDE PLATE - A4M04138
(x58) 1/16"x2 3/16"x6 9/16" (2x55x167)


- REPEAT THIS STEP 29 TIMES.
- DO NOT OVERTIGHTEN SCREWS.
- FOR EASE OF ASSEMBLY, WE RECOMMEND USING SAWHORSES FOR THIS STEP.



STEP 23A - LOUVER INSTALLATION




- STARTING AT LEFT, PLACE THE LOUVER ASSEMBLY FROM STEP 22 INTO THE FIRST SET OF LOUVER MOUNT GROOVES AT THE BACK OF THE UNIT.
- PLACE THE ASSEMBLY DOWN IN THE CORRESPONDING GROOVES IN THE FRONT.




STEP 23B - LOUVER INSTALLATION


Qty	PartNo	Description
1	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



- ON THE BACK SIDE, INSTALL FLAT BAR AND INSTALL ONE BOLT TO HOLD IN PLACE.
- ATTACH LOUVER TIE STRAP AND SLIDE OVER PINS ON LOUVER ASSEMBLIES



VIEW FROM WALL




STEP 23C - LOUVER INSTALLATION

Qty	PartNo	Description
1	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




H101161 COTTER PIN
(x4)




LOUVER ASSEMBLY STEP - 22
(x2)

- ON THE BACK SIDE, LIFT TIE STRAP AND FLAT BAR UP ENOUGH TO SLIDE LOUVERS INTO GROOVES IN LOUVER MOUNTS.
- SLIDE TIE STRAP ONTO PINS ON LOUVER ASSEMBLIES.
- SET LOUVER ASSEMBLIES IN CORRESPONDING HOLES IN FRONT OF UNIT.
- **MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.**
- ATTACH COTTER PINS TO EACH OF THE INSTALLED LOUVER BLADES ON THE BACK SIDE.




1202 (x1)
TORX PAN HEAD
1/4-20x3/4 ASSY



1161 (x4)
COTTER PIN

VIEW FROM WALL




LEFT

LOUVER ASSEMBLY
STEP 22


FRONT

STEP 23D - LOUVER INSTALLATION

Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



- ON THE BACK SIDE, LIFT TIE STRAP AND FLAT BAR UP ENOUGH TO SLIDE LOUVERS INTO GROOVES IN LOUVER MOUNTS.
- SLIDE TIE STRAP ONTO PINS ON LOUVER ASSEMBLIES.
- SET LOUVER ASSEMBLIES IN CORRESPONDING HOLES IN FRONT OF UNIT.
- **MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.**
- ATTACH FLAT BAR WITH TWO BOLTS.




STEP 23E - LOUVER INSTALLATION




H101161 COTTER PIN
(x4)

- MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.
- ATTACH COTTER PINS TO EACH OF THE INSTALLED LOUVER BLADES ON THE BACK SIDE.




STEP 23F - LOUVER INSTALLATION

Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



- LIFT TIE STRAP AND FLAT BAR UP ENOUGH TO SLIDE LOUVERS INTO GROOVES IN LOUVER MOUNTS.
- SLIDE TIE STRAP ONTO PINS ON LOUVER ASSEMBLIES.
- SET LOUVER ASSEMBLIES IN CORRESPONDING HOLES IN FRONT OF UNIT.
- **MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.**
- ATTACH FLAT BAR WITH TWO BOLTS.




STEP 23G - LOUVER INSTALLATION



H101161 COTTER PIN
(x4)


- MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.
- ATTACH COTTER PINS TO EACH OF THE INSTALLED LOUVER BLADES ON THE BACK SIDE.



1161 (x4)
COTTER PIN

F02
LOUVER STRAP

F01
FLAT BAR



LEFT


FRONT

LOUVER ASSEMBLY
STEP 22


STEP 23H - LOUVER INSTALLATION

Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY


F02 LOUVER STRAP - A4M04057
(x1) 1/8"x13/16"x101 3/4" (3x20x2585)



LOUVER ASSEMBLY STEP - 22
(x4)



- LIFT TIE STRAP AND FLAT BAR UP ENOUGH TO SLIDE LOUVERS INTO GROOVES IN LOUVER MOUNTS.
- SLIDE TIE STRAP ONTO PINS ON LOUVER ASSEMBLIES.
- SET LOUVER ASSEMBLIES IN CORRESPONDING HOLES IN FRONT OF UNIT.
- **MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.**
- ATTACH FLAT BAR WITH TWO BOLTS.




STEP 23I - LOUVER INSTALLATION





H101161 COTTER PIN
(x4)

- MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.
- ATTACH COTTER PINS TO EACH OF THE INSTALLED LOUVER BLADES ON THE BACK SIDE.




STEP 23J - LOUVER INSTALLATION

Qty	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




- LIFT TIE STRAP AND FLAT BAR UP ENOUGH TO SLIDE LOUVERS INTO GROOVES IN LOUVER MOUNTS.
- SLIDE TIE STRAP ONTO PINS ON LOUVER ASSEMBLIES.
- SET LOUVER ASSEMBLIES IN CORRESPONDING HOLES IN FRONT OF UNIT.
- **MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.**
- ATTACH FLAT BAR WITH THREE BOLTS.



STEP 23K - LOUVER INSTALLATION



- MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.
- ATTACH COTTER PINS TO EACH OF THE INSTALLED LOUVER BLADES ON THE BACK SIDE.







STEP 23L - LOUVER INSTALLATION

Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



- LIFT TIE STRAP AND FLAT BAR UP ENOUGH TO SLIDE LOUVERS INTO GROOVES IN LOUVER MOUNTS.
- SLIDE TIE STRAP ONTO PINS ON LOUVER ASSEMBLIES.
- SET LOUVER ASSEMBLIES IN CORRESPONDING HOLES IN FRONT OF UNIT.
- **MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.**
- ATTACH FLAT BAR WITH TWO BOLTS.


LOUVER ASSEMBLY
STEP - 22



STEP 23M - LOUVER INSTALLATION




- MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.
- ATTACH COTTER PINS TO EACH OF THE INSTALLED LOUVER BLADES ON THE BACK SIDE.





STEP 23N - LOUVER INSTALLATION

Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



- LIFT TIE STRAP AND FLAT BAR UP ENOUGH TO SLIDE LOUVERS INTO GROOVES IN LOUVER MOUNTS.
- SLIDE TIE STRAP ONTO PINS ON LOUVER ASSEMBLIES.
- SET LOUVER ASSEMBLIES IN CORRESPONDING HOLES IN FRONT OF UNIT.
- **MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.**
- ATTACH FLAT BAR WITH TWO BOLTS.


LOUVER ASSEMBLY
STEP - 22



STEP 230 - LOUVER INSTALLATION



- MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.
- ATTACH COTTER PINS TO EACH OF THE INSTALLED LOUVER BLADES ON THE BACK SIDE.



STEP 23P - LOUVER INSTALLATION

Qty	PartNo	Description
1	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




- LIFT TIE STRAP AND FLAT BAR UP ENOUGH TO SLIDE LOUVERS INTO GROOVES IN LOUVER MOUNTS.
- SLIDE TIE STRAP ONTO PINS ON LOUVER ASSEMBLIES.
- SET LOUVER ASSEMBLIES IN CORRESPONDING HOLES IN FRONT OF UNIT.
- **MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.**
- ATTACH FLAT BAR WITH ONE BOLT.

LOUVER ASSEMBLY
STEP - 22

F02
LOUVER STRAP

1202 (x1)
TORX PAN HEAD
1/4-20x3/4 ASSY


F01
FLAT BAR



STEP 23Q - LOUVER INSTALLATION




- MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION.
- ATTACH COTTER PINS TO EACH OF THE INSTALLED LOUVER BLADES ON THE BACK SIDE.




STEP 24 - LOUVER INSTALLATION

Qty	PartNo	Description
16	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




F01 FLAT BAR - A4M04056
(x2) 1/16"x1"x99 9/16" (2x25x2528)

- ON THE FRONT SIDE, ATTACH FLAT BAR ALONG EACH LOUVER MOUNT. FLAT BAR WILL HOLD ALL LOUVERS IN PLACE.





STEP 25A - LOUVER INSTALLATION



F02 LOUVER STRAP - A4M04057
(x2) 1/8"x13/16"x101 3/4" (3x20x2585)

- LOUVER TIE STRAPS WILL CONNECT ALL LOUVERS TO ONE ANOTHER.
- STARTING ON THE LEFT AND WORKING TO THE RIGHT, CONNECT LOUVERS USING TIE STRAPS. OVERLAP TIE STRAPS TO HOLD MIDDLE LOUVERS TOGETHER.





STEP 25B - LOUVER INSTALLATION



H101161 COTTER PIN
(x30)

- INSTALL COTTER PINS ON EACH LOUVER TO HOLD TIE STRAPS IN PLACE.
- CONFIRM ALL HARDWARE HAS BEEN TIGHTENED FROM PREVIOUS STEPS.



STEP 26 - LOUVER MECHANISM




L04 BODY HALF - A4M02132
(x1) 11/16"x2 1/2"x2 7/8" (17x64x73)



F06 SPACER - A4M02227
(x1) 1/16"x2 3/16"x2 3/4" (1.5x56x70)

Qty	PartNo	Description
4	H101126	TORX PAN HEAD 1/4-20x2 1/8" BLK

- ALIGN SCREW HOLES.



L04 (x1)
BODY HALF

F06 (x1)
SPACER

1126 (x4)
TORX PAN HEAD
1/4-20x2 1/8"

STEP 27 - LOUVER MECHANISM





F07 COVER - A4M02228
(x1) 1 9/16"x2 7/8"x3 1/4" (39.5x73x82)



F05 KEY STOCK - A4M02226
(x1) 1/2"x1/2"x3 3/4" (13.0x13.0x95)

Qty	PartNo	Description
1	H101187	BOLT PPH 8-32x1 1/8 BLK

- ALIGN SCREW HOLES.



STEP 28A - LOUVER MECHANISM

Qty	PartNo	Description
2	H100474	WASHER FLAT 9x18 BLK
1	H100653	NUT LOCK 1/4 BLK
1	H101189	LOW PROFILE SHOULDER BOLT 1/4-20x3/8" BLK




F03 LINKAGE STRAP - A4M02229
(x1) 1/8"x11/16"x3 13/16" (3x17x97)




F04 LINKAGE STRAP - A4M02225
(x1) 1/8"x13/16"x2 5/8" (3x20x66)

- LINKAGES MUST BE ORIENTED AS SHOWN BELOW.

- DO NOT OVERTIGHTEN HARDWARE.
- LINKAGES SHOULD BE ABLE TO ROTATE FREELY.



STEP 28B - LOUVER MECHANISM





LINKAGE ASSEMBLY
STEP - 28A

Qty	PartNo	Description
1	H100774	WASHER SPLIT 1/4 BLK
3	H100474	WASHER FLAT - 9x18 BLK
1	H101101	TORX PAN HEAD 1/4-20x3/4"BLK
1	H100653	NUT LOCK 1/4 BLK
1	H101189	LOW PROFILE SHOULDER BOLT 1/4-20x3/8" BLK

- LINKAGES MUST BE ORIENTED AS SHOWN BELOW.


- DO NOT OVERTIGHTEN HARDWARE.
- LINKAGES SHOULD BE ABLE TO ROTATE FREELY.



STEP 28C - LOUVER MECHANISM




- CONNECT CRANK HANDLE TO MECHANISM. TURN HANDLE TO LOCK IN PLACE



STEP 29 - PERGOLA ANCHORING


Qty	PartNo	Description
8	H100630	WASHER FLAT 8x19 BLK
8	H101305	CONCRETE ANCHOR 1/4"x3" BLK



A4M04024 SHIM
(x4)


NOTES:


- MANUFACTURER RECOMMENDS INSTALLATION ON CONCRETE SURFACE OR CONCRETE POST PADS. SEE BELOW.
- FOR INSTALLATION ON WOOD DECKS, YOU MUST ENSURE THERE IS AMPLE STRUCTURAL SUPPORT UNDER DECK.
- PRE-DRILL HOLES FOR CONCRETE ANCHORS USING A 3/16" [5mm] CONCRETE DRILL BIT.
- REPEAT THIS STEP FOR TWO POSTS.
- THERE NEEDS TO BE A SLIGHT SLOPE AWAY FROM INSTALLATION WALL TO ALLOW FOR PROPER DRAINAGE FLOW.



STEP 30 - PREVENTATIVE MAINTENANCE

NOTE: IT IS IMPORTANT TO TAKE CAUTION WHEN HIGH WINDS OR WINTER WEATHER SUCH AS ICE OR SNOW IS EXPECTED. IF INCLEMENT WEATHER ARISES, IT IS RECOMMENDED TO TURN LOUVERS INTO THE FULLY OPEN (UPRIGHT) POSITION. THIS WILL PREVENT DAMAGE TO THE STRUCTURE AND DECREASE THE CHANCES OF STRUCTURE OR LOUVER DAMAGE.





9205413 | **ELECTRICAL ENCLOSURE**
(x1)