



Manufactured by:  
Backyard Discovery  
3305 Airport Drive, Pittsburg,  
KS 66762 800-856-4445

Basepoint Business Centre: Rivermead Drive, Westlea, Swindon SN5 7EX Phone: 0800-118-2476  
J.P. Coenstraat 7, The Bridge, The Hague, 2595 WP, Netherlands Phone: 08005678990

# 20x10 SARASOTA LOUVERED PERGOLA

## MODEL # : 2305120B / 2305120B-I



### WARNING

Cancer and Reproductive Harm  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)



Please visit [www.backyarddiscovery.com](http://www.backyarddiscovery.com)

For the most up to date assembly manual, to register your product, or to order replacement parts *Para obtener instrucciones en español, visite*  
[www.backyarddiscovery.com](http://www.backyarddiscovery.com)



EASY STEP-BY-STEP

3D INTERACTIVE INSTRUCTIONS

DOWNLOAD THE FREE APP




# OWNER'S MANUAL - BASIC SETUP DIMENSIONS & ASSEMBLY NOTES

It is critically important that you start with square and level footings, concrete pad or deck to attach your structure


- Pay close attention to the items needed for each step. Make sure you are using the correct hardware for each step. Using incorrect hardware may result in improper assembly
- Remember to double check for underground utilities and overhead electrical lines

Post mounts are provided with your structure which allows you to permanently install your structure to a pre-existing or new wood or concrete surface. See Anchor Instructions for further details and recommendations.

- The hardware to attach the post mounts to the structure is included.
- The hardware to mount the structure permanently to a concrete surface is included.
- The hardware to mount the structure permanently to a wood deck is NOT included and will need to be purchased separately. You must ensure there is ample structural support under the deck before permanently attaching.




# OWNER'S MANUAL - ANCHORING LAYOUT




# OWNER'S MANUAL - PARTS IDENTIFICATION


## METAL COMPONENTS (NOT TO SCALE)




P01 POST - A4M01983  
(x1) 4 5/16"x6 3/4"x99 1/2" (110x172x2527)



P02 POST - A4M01984  
(x2) 4 5/16"x6 3/4"x99 1/2" (110x172x2527)



P03 POST - A4M02131  
(x1) 4 5/16"x6 3/4"x99 1/2" (110x172x2527)



P04 POST - A4M02587  
(x2) 4 5/16"x6 3/4"x99 7/16" (110x172x2525.5)



G02 GUTTER - A4M02583  
(x4) 1 9/16"x1 15/16"x111" (40x50x2819)



G01 GUTTER - A4M01993  
(x2) 1 9/16"x1 15/16"x108 7/8" (40x50x2765)



M01 LOUVER MOUNT - A4M02593  
(x1) 1"x1 15/16"x110 3/4" (25x49x2813)



M02 LOUVER MOUNT - A4M02594  
(x1) 1"x1 15/16"x110 3/4" (25x49x2813)



M04 LOUVER MOUNT - A4M02596  
(x1) 1"x1 15/16"x110 3/4" (25x49x2813)





M03 LOUVER MOUNT - A4M02595  
(x1) 1"x1 15/16"x110 3/4" (25x49x2813)



# OWNER'S MANUAL - PARTS IDENTIFICATION

## METAL COMPONENTS (NOT TO SCALE)



B01 BEAM - A4M01986  
(x2) 1 7/16"x5 1/4"x114 1/2" (36x134x2910)




B02 BEAM - A4M02588  
(x1) 1 7/16"x5 1/4"x72 7/16" (36x134x1839)



B03 BEAM - A4M02589  
(x1) 1 7/16"x5 1/4"x72 7/16" (36x134x1839)



B04 BEAM - A4M02590  
(x1) 1 7/16"x5 1/4"x72 7/16" (36x134x1839)



B05 BEAM - A4M02591  
(x2) 1 7/16"x5 1/4"x89 7/8" (36x134x2283)




B06 BEAM - A4M02592  
(x1) 1 7/16"x5 1/4"x72 7/16" (36x134x1839)



J1 SPLICE BRACKET - A4M02230  
(x4) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)

# OWNER'S MANUAL - PARTS IDENTIFICATION

## METAL COMPONENTS (NOT TO SCALE)



L02 LOUVER DRIVE SIDE PLATE - A4M04139  
(x2) 1/16"x2 3/16"x6 9/16" (2x55x167)



L03 LOUVER SIDE PLATE - A4M04138  
(x66) 1/16"x2 3/16"x6 9/16" (2x55x167)



F05 KEY STOCK - A4M02226  
(x2) 1/2"x1/2"x3 3/4" (13x13x95)



F07 COVER - A4M02228  
(x2) 1 9/16"x2 7/8"x3 1/4" (39.5x73x82)



F04 LINKAGE STRAP - A4M02225  
(x2) 1/8"x13/16"x2 5/8" (3x20x66)



F03 LINKAGE STRAP - A4M02229  
(x2) 1/2"x11/16"x3 13/16" (13x17x97)




F06 SPACER - A4M02227  
(x2) 1/16"x2 3/16"x2 3/4" (1.5x56x70)



H01 HANDLE  
(x2) A4M04022




A6P00796 SILICONE  
(x1)




9205413 ELECTRICAL  
(x1) ENCLOSURE

# OWNER'S MANUAL - PARTS IDENTIFICATION

## HARDWARE COMPONENTS (NOT TO SCALE)




H101202 TORX PAN HEAD  
(x176) 1/4-20x3/4" ASSY




H101101 TORX PAN HEAD  
(x2) 1/4-20x3/4" BLK



H101126 TORX PAN HEAD  
(x8) 1/4-20x2 1/8" BLK



H101187 BOLT PPH  
(x2) 8-32x1 1/8" BLK



H101189 LOW PROFILE SHOULDER BOLT  
(x4) 1/4-20x3/8" BLK



H100408 SCREW PWH  
(x136) 8x1/2 BLK



H100120 CONCRETE  
(x24) ANCHOR



H101230 BOLT WH  
(x20) 5/16x6 S.S



H101161 COTTER PIN  
(x68)



H100474 WASHER FLAT  
(x10) 9x19 BLK



H100630 WASHER FLAT  
(x24) 8x19 BLK



H100653 NUT LOCK  
(x4) 1/4 BLK



H100774 WASHER SPLIT  
(x2) 1/4 BLK



H100147 TORX BIT  
(x1) T-30



H100114 TORX WRENCH  
(x1) T-30



H101100 MAGNETIC DRIVER  
(x1)



H101114 RIGHT ANGLE  
(x1) DRILL ADAPTER

# PRE-ASSEMBLY STEP 1 - SORTING PARTS


It is critical for ease of assembly that you take the time to sort and organize the parts and hardware.

---

## METAL PARTS:

- Organize metal parts by the three-digit, alpha-numeric number stamped on each part (ex. P01).
- If there are multiple parts with the same stamped number, stack those pieces together.
- Stamps can be found on the flat surface of the parts or on the end of the parts.
- Allow yourself plenty of room - the parts can take up a significant amount of space.


**NOTE: CARTONS ARE NOT ORGANIZED BY PART NUMBER.  
IT IS RECOMMENDED TO LEAVE LOUVER ASSEMBLIES IN BOX UNTIL NEEDED.**



---

## HARDWARE PARTS:

- We recommend that you have a separate table to organize the hardware.
- Hardware bags are printed with a seven-digit, alpha-numeric part number.
- You can organize your hardware by part number or group by hardware type (i.e. bolts, nuts, etc.).
- During assembly you only need to reference the last four digits of the number.




PRE-ASSEMBLY STEP 2 - TOOLS REQUIRED



Cordless Drill  
or Electric Drill



Drill  
Attachments:  
Phillips Head



1/8", 3/16", 3/8" &  
7/16" Drill Bits



Phillips Screw Driver



Open End  
Wrench 7/16"




3/8" Drive Ratchet, 1/2" &  
7/16" STD Sockets 1/2" & 7/16"  
Deep Sockets




Claw Hammer



Rubber Mallet  
- Optional



Tape Measure



Square




Level 24"

# PRE-ASSEMBLY STEP 3 - CHOOSE YOUR ASSEMBLY METHOD

There are several types of assembly instructions available to you.

1. Printed Assembly Manual included with your set
2. BILT APP - 3D interactive instructions
3. Combination of the Printed Manual and BILT APP (Note: Step numbers can differ between the two methods)



# STEP 1 - BEAM ASSEMBLY

QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



B03 BEAM - A4M02589  
(x1) 1 7/16"x5 1/4"x72 7/16" (36x134x1839)




J1 SPLICE BRACKET - A4M02230  
(x1) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)

**DO NOT TIGHTEN HARDWARE AT THIS STEP**

FOR EASE OF ASSEMBLY, WE RECOMMEND  
USING SAWHORSES FOR STEPS 1 - 11

1202 (x6)  
TORX PAN HEAD 1/4-20x3/4 ASSY

**NOTE: BEAM AND SPLICE MUST BE  
ORIENTED AS SHOWN BELOW.  
SLIDE J1 INTO B03 AND LINE UP  
THREE HOLES TOP AND BOTTOM.**





# STEP 2 - BEAM ASSEMBLY


QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



B05 BEAM - A4M02591  
(x1) 1 7/16"x5 1/4"x89 7/8" (36x134x2283)


SLIDE B05 INTO SPLICE BRACKET.  
GENTLY TAP ENDS OF ASSEMBLY WITH  
RUBBER Mallet UNTIL GAP CLOSSES,  
THEN TIGHTEN ALL BOLTS ON BEAM.

NOTE: SMALL OVAL HOLES  
INDICATE TOP SURFACE OF BEAM




1202 (x6)  
TORX PAN HEAD  
1/4-20x3/4 ASSY

NOTE: ALL THREADED  
INSERTS WILL BE ON  
THE SAME SIDE OF  
THE BEAM



B05 (x1)  
BEAM

B03  
BEAM




STEP 3 - BEAM ASSEMBLY



J1 SPLICE BRACKET - A4M02230  
(x1) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)

QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

DO NOT TIGHTEN HARDWARE AT THIS STEP




# STEP 4 - BEAM ASSEMBLY

QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



B02 BEAM - A4M02588  
(x1) 1 7/16"x5 1/4"x72 7/16" (36x134x1839)

SLIDE B02 INTO SPLICE BRACKET.  
GENTLY TAP ENDS OF ASSEMBLY WITH  
RUBBER Mallet UNTIL GAP CLOSES,  
THEN TIGHTEN ALL BOLTS ON BEAM.





1202 (x6)  
TORX PAN HEAD 1/4-20x3/4 ASSY

B02 (x1)  
BEAM



# STEP 5A - FRAME ASSEMBLY

QTY	PartNo	Description
2	H101230	BOLT WH 5/16x6 S.S.




ATTACH BEAM ASSEMBLY TO POST BY ALIGNING SLOTS IN BEAM WITH THREADED INSERTS ON TOP POST PLATE. FLUSH ALL SIDES OF BEAM AND POST BEFORE TIGHTENING HARDWARE

NOTE: LARGE SLOTS INDICATE BOTTOM SURFACE OF BEAM. SLOTS WILL FIT AROUND THREADED INSERTS IN POST PLATE.




NOTE: POST BRACKET WILL FIT AROUND THREADED INSERTS IN BEAM



P02 (x1)  
POST


# STEP 5B - FRAME ASSEMBLY

QTY	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY





STEP 6A - FRAME ASSEMBLY




P04 POST - A4M02587  
(x1) 4 5/16"x6 3/4"x99 7/16" (110x172x2525.5)


QTY	PartNo	Description
2	H101230	BOLT WH 5/16x6 S.S.

ATTACH BEAM ASSEMBLY TO POST BY ALIGNING SLOTS IN BEAM WITH THREADED INSERTS ON TOP POST PLATE. FLUSH ALL SIDES OF BEAM AND POST BEFORE TIGHTENING HARDWARE


NOTE: LARGE SLOTS INDICATE BOTTOM SURFACE OF BEAM. SLOTS WILL FIT AROUND THREADED INSERTS IN POST PLATE.



BACK VIEW



NOTE: POST BRACKET WILL FIT AROUND THREADED INSERTS IN BEAM




BEAM ASSEMBLY  
STEPS 1-4

P04 (x1)  
POST

P02  
POST


# STEP 6B - FRAME ASSEMBLY

QTY	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY






STEP 7A - FRAME ASSEMBLY





QTY	PartNo	Description
2	H101230	BOLT WH 5/16x6 S.S.

ATTACH BEAM ASSEMBLY TO POST BY ALIGNING SLOTS IN BEAM WITH THREADED INSERTS ON TOP POST PLATE. FLUSH ALL SIDES OF BEAM AND POST BEFORE TIGHTENING HARDWARE

NOTE: LARGE SLOTS INDICATE BOTTOM SURFACE OF BEAM. SLOTS WILL FIT AROUND THREADED INSERTS IN POST PLATE.




NOTE: POST BRACKET WILL FIT AROUND THREADED INSERTS IN BEAM




# STEP 7B - FRAME ASSEMBLY

QTY	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




# STEP 8 - LOUVER MOUNT ATTACHMENT



QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

M01 LOUVER MOUNT - A4M02593  
(x1) 1"x1 15/16"x110 3/4" (25x49x2813)



STEP 9 - LOUVER MOUNT ATTACHMENT




QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

M03 LOUVER MOUNT - A4M02595  
(x1) 1"x1 15/16"x110 3/4" (25x49x2813)

1202 (x6)  
TORX PAN HEAD 1/4-20x3/4 ASSY


NOTE: FLUSH MOUNT  
WITH EDGE OF POST  
BRACKET

NOTE: LOUVER MOUNT WILL  
FIT AROUND THREADED  
INSERTS IN BEAM






# STEP 10 - GUTTER ATTACHMENT




QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

ATTACH GUTTER TO BEAM MAKING SURE  
EACH END OF GUTTER SITS ON TOP SURFACE  
OF EACH POST BRACKET




# STEP 11 - GUTTER ATTACHMENT




QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

ATTACH GUTTER TO BEAM MAKING SURE  
EACH END OF GUTTER SITS ON TOP SURFACE  
OF EACH POST BRACKET



# STEP 12A - FRAME ASSEMBLY

QTY	PartNo	Description
4	H101230	BOLT WH 5/16x6 S.S.



P03 POST - A4M02131  
(x1) 4 5/16"x6 3/4"x99 1/2" (110x172x2527)


B01 BEAM - A4M01986  
(x1) 1 7/16"x5 1/4"x114 1/2" (36x134x2910)

WITH AT LEAST THREE EXTRA PEOPLE, STAND UP FRAME ASSEMBLY FROM PREVIOUS STEPS AND ATTACH B01 BEAM TO P02 AND P03 POST.


ALIGN SLOTS IN BEAM WITH THREADED INSERTS ON TOP PLATE OF EACH POST. FLUSH ALL SIDES OF BEAM AND POST.

DO NOT TIGHTEN HARDWARE AT THIS STEP

NOTE: LARGE SLOTS INDICATE BOTTOM SURFACE OF BEAM. SLOTS WILL FIT AROUND THREADED INSERTS IN POST PLATE.



BACK VIEW




NOTE: POST BRACKET WILL FIT AROUND THREADED INSERTS IN BEAM



# STEP 12B - FRAME ASSEMBLY

QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

DO NOT TIGHTEN HARDWARE AT THIS STEP



# STEP 13 - GUTTER ATTACHMENT




QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

G01 GUTTER - A4M01993  
(x1) 1 9/16"x1 15/16"x108 7/8" (40x50x2765)

WITH AN ADDITIONAL PERSON, ATTACH GUTTER TO BEAM.  
MAKE SURE ENDS OF GUTTER SIT ON TOP SURFACE OF EACH  
POST BRACKET.

TIGHTEN ALL HARDWARE FROM PREVIOUS STEPS



## STEP 14A - FRAME ASSEMBLY


QTY	PartNo	Description
4	H101230	BOLT WH 5/16x6 S.S.



**WITH AT LEAST TWO EXTRA PEOPLE, ATTACH B01 BEAM TO P02 AND P01 POST.**


**ALIGN SLOTS IN BEAM WITH THREADED INSERTS ON TOP POST PLATE. FLUSH ALL SIDES OF BEAM AND POST.**

**DO NOT TIGHTEN HARDWARE AT THIS STEP.**




**NOTE: LARGE SLOTS INDICATE BOTTOM SURFACE OF BEAM. SLOTS WILL FIT AROUND THREADED INSERTS IN POST PLATE.**

**NOTE: POST BRACKET WILL FIT AROUND THREADED INSERTS IN BEAM**



BACK VIEW




# STEP 14B - FRAME ASSEMBLY

QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

DO NOT TIGHTEN HARDWARE AT THIS STEP

NOTE: MAKE SURE POST  
BRACKET SITS AROUND  
THREADED INSERTS IN BEAM

1202 (x6)  
TORX PAN HEAD 1/4-20x3/4 ASSY





# STEP 15 - GUTTER ATTACHMENT




QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

G01 GUTTER - A4M01993  
(x1) 1 9/16"x1 15/16"x108 7/8" (40x50x2765)


WITH AN ADDITIONAL PERSON, ATTACH GUTTER TO BEAM.  
MAKE SURE ENDS OF GUTTER SIT ON TOP SURFACE OF EACH  
POST BRACKET.

TIGHTEN ALL HARDWARE FROM PREVIOUS STEPS



# STEP 16 BEAM ASSEMBLY

QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



B05 BEAM - A4M02591  
(x1) 1 7/16"x5 1/4"x89 7/8" (36x134x2283)




J1 SPLICE BRACKET - A4M02230  
(x1) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)

**DO NOT TIGHTEN HARDWARE AT THIS STEP**

FOR EASE OF ASSEMBLY, WE RECOMMEND USING SAWHORSES FOR STEPS 16 - 18

**NOTE: BEAM AND SPLICE MUST BE ORIENTED AS SHOWN BELOW. SLIDE J1 INTO B05 AND LINE UP THREE HOLES TOP AND BOTTOM.**



STEP 17 - BEAM ASSEMBLY


QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



B04 BEAM - A4M02590  
(x1) 1 7/16"x5 1/4"x72 7/16" (36x134x1839)


SLIDE B04 INTO SPLICE BRACKET.  
GENTLY TAP ENDS OF ASSEMBLY WITH  
RUBBER Mallet UNTIL GAP CLOSES,  
THEN TIGHTEN ALL BOLTS ON BEAM.

1202 (x6)  
TORX PAN HEAD 1/4-20x3/4 ASSY



NOTE: ALL THREADED  
INSERTS WILL BE ON  
THE SAME SIDE OF  
THE BEAM

B04 (x1)  
BEAM





# STEP 18A - FRAME ASSEMBLY

QTY	PartNo	Description
2	H101230	BOLT WH 5/16x6 S.S.


P04 POST - A4M02587  
(x1) 4 5/16"x6 3/4"x99 7/16" (110x172x2525.5)



BEAM ASSEMBLY  
STEPS 16 - 17


ATTACH BEAM ASSEMBLY TO POST BY ALIGNING SLOTS IN BEAM WITH THREADED INSERTS ON TOP POST PLATE. FLUSH ALL SIDES OF BEAM AND POST BEFORE TIGHTENING HARDWARE

NOTE: LARGE SLOTS INDICATE  
BOTTOM SURFACE OF BEAM.  
SLOTS WILL FIT AROUND THREADED  
INSERTS IN POST PLATE.




1230 (x2)  
BOLT - 6"

NOTE: POST BRACKET WILL  
FIT AROUND THREADED  
INSERTS IN BEAM



BACK VIEW




BEAM ASSEMBLY  
STEPS 16 - 17

P04 (x1)  
POST

# STEP 18B - BEAM ASSEMBLY

QTY	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



# STEP 19A - FRAME ASSEMBLY



BEAM/POST ASSEMBLY  
STEPS 16 -18


QTY	PartNo	Description
2	H101230	BOLT WH 5/16x6 S.S.

WITH AT LEAST TWO ADDITIONAL PEOPLE, ATTACH BEAM ASSEMBLY FROM PREVIOUS STEPS TO P03 POST. ALIGN SLOTS IN BEAM WITH THREADED INSERTS ON TOP POST PLATE. FLUSH ALL SIDES OF BEAM AND POST.




DO NOT TIGHTEN HARDWARE AT THIS STEP.

NOTE: POST BRACKET WILL  
FIT AROUND THREADED  
INSERTS IN BEAM

1230 (x2)  
BOLT - 6"



BACK VIEW




# STEP 19B - FRAME ASSEMBLY

QTY	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

DO NOT TIGHTEN HARDWARE AT THIS STEP

1202 (x3)  
TORX PAN HEAD 1/4-20x3/4 ASSY

NOTE: MAKE SURE POST  
BRACKET SITS AROUND  
THREADED INSERTS IN BEAM




# STEP 20 - FRAME ASSEMBLY

QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



J1 SPLICE BRACKET - A4M02230  
(x1) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)

DO NOT TIGHTEN HARDWARE AT THIS STEP






# STEP 21A - FRAME ASSEMBLY

QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



B06 BEAM - A4M02592  
(x1) 1 7/16"x5 1/4"x72 7/16" (36x134x1839)

SLIDE B06 INTO SPLICE BRACKET.  
GENTLY TAP END OF BEAM WITH  
RUBBER Mallet UNTIL GAP CLOSSES.  
DO NOT TIGHTEN HARDWARE AT THIS STEP




# STEP 21B - FRAME ASSEMBLY

QTY	PartNo	Description
2	H101230	BOLT WH 5/16x6 S.S.

ALIGN SLOTS IN BEAM WITH THREADED INSERTS ON TOP POST PLATE. FLUSH ALL SIDES OF BEAM AND POST.


DO NOT TIGHTEN HARDWARE AT THIS STEP




# STEP 21C - FRAME ASSEMBLY

QTY	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

TIGHTEN ALL HARDWARE FROM PREVIOUS STEPS




# STEP 22 - LOUVER MOUNT ATTACHMENT



M04 LOUVER MOUNT - A4M02596  
(x1) 1"x1 15/16"x110 3/4" (25x49x2813)

QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




# STEP 23 - LOUVER MOUNT ATTACHMENT




QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

M02 LOUVER MOUNT - A4M02594  
(x1) 1"x1 15/16"x110 3/4" (25x49x2813)







# STEP 24 - GUTTER ATTACHMENT



G02 GUTTER - A4M02583  
(x1) 1 9/16"x1 15/16"x111" (40x50x2819)

QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

ATTACH GUTTER TO BEAM MAKING SURE  
EACH END OF GUTTER SITS ON TOP SURFACE  
OF EACH POST BRACKET



NOTE: GUTTER FLANGE  
WILL OVERLAP EDGE  
OF POST


1202 (x6)  
TORX PAN HEAD 1/4-20x3/4 ASSY

G02 (x1)  
GUTTER

P02  
POST


P04  
POST

# STEP 25 - GUTTER ATTACHMENT



QTY	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY


ATTACH GUTTER TO BEAM MAKING SURE  
EACH END OF GUTTER SITS ON TOP SURFACE  
OF EACH POST BRACKET



# STEP 26A - SQUARE STRUCTURE

- CRITICAL:**  
1. SQUARE ASSEMBLY BEFORE PROCEEDING TO NEXT STEPS.  
2. ONCE SQUARE, TIGHTEN ALL HARDWARE.



MEASUREMENTS TAKEN FROM OUTSIDE OF POST  
TO OUTSIDE OF POST UNLESS NOTED OTHERWISE



## STEP 26B - POSITIONING THE STRUCTURE

### CRITICAL:

- FOR YOUR PERGOLA TO DRAIN PROPERLY, THERE MUST BE A SLIGHT SLOPE ON THE 10FT SIDE RUNNING THE LENGTH OF THE LOUVER BLADES.
- IT IS RECOMMENDED THAT THE LONG SIDES ARE LEVEL OR CLOSE TO LEVEL.
- PLACE A LEVEL ON THE LONGER BEAMS TO CONFIRM THE LONG SIDES ARE CLOSE TO LEVEL.
- PLACE A LEVEL ON THE SHORT BEAMS (10FT) SIDE TO CONFIRM YOU HAVE A SLIGHT SLOPE IN ONE DIRECTION.



PLEASE CONTACT BACKYARD DISCOVERY CUSTOMER SERVICE  
IF HELP IS NEEDED POSITIONING YOUR STRUCTURE

## STEP 27 - GUTTER SEALANT



A6P00796 SILICONE  
(x1)

**APPLY A FINE BEAD OF SILICONE ALONG INSIDE SURFACE OF GUTTER WHERE GUTTER PIECES MEET POST.**



**SMOOTH SILICONE, WIPING EXCESS USING A RAG OR PAPER TOWEL**

**REPEAT THIS STEP FOR ALL GUTTER ATTACHMENT POINTS AT EACH POST**

**TIP: GLOVES ARE RECOMMENDED WHEN APPLYING SILICONE.**

**MAKE SURE SURFACE OF GUTTER IS CLEAN, DRY, AND FREE OF ANY DIRT/DEBRIS**

**NOTE: APPLY A FINE BEAD OF SILICONE TO PREVENT WATER FROM LEAKING**






# STEP 28 - DRIVE LOUVER ASSEMBLY


Qty	PartNo	Description
8	H100408	SCREW PWH 8x1/2 BLK



L02 LOUVER DRIVE SIDE PLATE - A4M04139  
(x2) 1/16"x2 3/16"x6 9/16" (2x55x167)




L03 LOUVER SIDE PLATE - A4M04138  
(x2) 1/16"x2 3/16"x6 9/16" (2x55x167)




L01 LOUVER - A4M04137  
(x2) 1 11/16"x7 3/4"x114 5/16" (42x196x2904)

**REPEAT THIS STEP TWICE.**  
**DO NOT OVERTIGHTEN SCREWS.**  
FOR EASE OF ASSEMBLY, WE RECOMMEND USING  
SAWHORSES FOR THIS STEP




# STEP 29 - DRIVE LOUVER INSTALLATION



DRIVE LOUVER ASSEMBLY  
STEP 28


ORIENTATION OF LOUVER WILL BE DETERMINED BY  
THE SIDE BEAM WITH FOUR THREADED INSERTS

NOTE: PLACE DRIVE LOUVER  
ASSEMBLY IN THE SECOND  
SET OF LOUVER MOUNT  
GROOVES




L02  
LOUVER DRIVE  
SIDE PLATE


NOTE: L02 SIDE PLATE  
MUST BE ON THE SAME  
END AS THE FOUR  
THREADED INSERTS



DRIVE LOUVER  
ASSEMBLY  
STEP 28




# STEP 30 - DRIVE LOUVER INSTALLATION



DRIVE LOUVER ASSEMBLY  
STEP 28



ORIENTATION OF LOUVER WILL BE DETERMINED BY  
THE SIDE BEAM WITH FOUR THREADED INSERTS






# STEP 31 - LOUVER ASSEMBLY


Qty	PartNo	Description
128	H100408	SCREW PWH 8x1/2 BLK



**REPEAT THIS STEP 32 TIMES.**  
**DO NOT OVERTIGHTEN SCREWS.**  
FOR EASE OF ASSEMBLY, WE RECOMMEND  
USING SAWHORSES FOR THIS STEP.






# STEP 32 - LOUVER INSTALLATION




STARTING AT THE LEFT SIDE AND WORKING TO THE RIGHT, CAREFULLY SET EACH LOUVER ASSEMBLY ONE AT A TIME INTO LOUVER MOUNTS AT EACH END

NOTE: MAKE SURE ALL LOUVER BLADE ASSEMBLIES ARE ORIENTED IN THE SAME DIRECTION






# STEP 33 - LOUVER INSTALLATION




QTY	PartNo	Description
36	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

F01 FLAT BAR - A4M02585  
(x4) 1/16"x1"x110 3/4" (2x25x2813)

ATTACH FLAT BAR ALONG EACH LOUVER MOUNT.  
FLAT BAR WILL HOLD ALL LOUVERS IN PLACE.




## STEP 34A - LOUVER INSTALLATION




**LOUVER TIE STRAPS WILL CONNECT LOUVERS TO ONE ANOTHER**

**STARTING AT THE ENDS OF THE ASSEMBLY, CONNECT LOUVERS USING TIE STRAPS.**



**START LOUVER TIE STRAP AT EACH END**

**START LOUVER TIE STRAP AT EACH END**






# STEP 34B - LOUVER INSTALLATION




H101161 COTTER PIN  
(x68)

INSTALL COTTER PINS ON EACH LOUVER  
TO HOLD TIE STRAPS IN PLACE




1161 (x68)  
COTTER PIN




# STEP 35 - LOUVER MECHANISM

QTY	PartNo	Description
8	H101126	TORX PAN HEAD 1/4-20x2 1/8"



# STEP 36 - LOUVER MECHANISM

QTY	PartNo	Description
2	H101187	BOLT PPH 8-32x1 1/8 BLK




F07 COVER - A4M02228  
(x2) 1 9/16"x2 7/8"x3 1/4" (39.5x73x82)



F05 KEY STOCK - A4M02226  
(x2) 1/2"x1/2"x3 3/4" (13x13x95)

REPEAT THIS STEP FOR BOTH  
MECHANISMS AT EACH END OF  
ASSEMBLY





# STEP 37A - LOUVER MECHANISM

QTY	PartNo	Description
2	H100653	NUT LOCK 1/4 BLK
2	H101189	LOW PROFILE SHOULDER BOLT 1/4-20x.375
4	H100474	WASHER FLAT 9x18 BLK



F03 LINKAGE STRAP - A4M02229  
(x2) 1/2"x11/16"x3 13/16" (13x17x97)




F04 LINKAGE STRAP - A4M02225  
(x2) 1/8"x13/16"x2 5/8" (3x20x66)


LINKAGES MUST BE ORIENTED AS SHOWN BELOW.  
DO NOT OVERTIGHTEN HARDWARE.

LINKAGES SHOULD BE ABLE TO ROTATE FREELY.

REPEAT THIS STEP TWICE



# STEP 37B - LOUVER MECHANISM





LINKAGE ASSEMBLY  
STEP 37A

QTY	PartNo	Description
2	H100653	NUT LOCK 1/4 BLK
2	H101189	LOW PROFILE SHOULDER BOLT 1/4-20x.375
2	H101101	TORX PAN HEAD 1/4-20x3/4"
2	H100774	WASHER SPLIT 1/4 BLK
6	H100474	WASHER FLAT 9x18 BLK

LINKAGES MUST BE ORIENTED AS SHOWN BELOW.  
DO NOT OVERTIGHTEN HARDWARE.

LINKAGES SHOULD BE ABLE TO ROTATE FREELY.


REPEAT THIS STEP FOR BOTH MECHANISMS AT EACH END.



# STEP 37C - LOUVER MECHANISM



CONNECT CRANK HANDLE TO MECHANISMS.  
TURN HANDLE TO LOCK IN PLACE.





# STEP 38 - PERGOLA ANCHORING


QTY	PartNo	Description
24	H100120	CONCRETE ANCHOR 1/4"x2"
24	H100630	WASHER FLAT 8x19 BLK

**NOTES:**  
MANUFACTURER RECOMMENDS INSTALLATION ON CONCRETE SURFACE OR CONCRETE POST PADS. SEE BELOW.

FOR INSTALLATION ON WOOD DECKS, YOU MUST ENSURE THERE IS AMPLE STRUCTURAL SUPPORT UNDER DECK.

**NOTES:**  
PRE-DRILL HOLES FOR CONCRETE ANCHORS USING A 3/16" CONCRETE DRILL BIT.

REPEAT THIS STEP FOR ALL 6 POST.




120 (x4)  
CONCRETE SCREW-2"


630 (x4)  
WASHER - 8x19

## STEP 39 - PREVENTATIVE MAINTENANCE

**NOTE - IT IS IMPORTANT TO TAKE CAUTION WHEN HIGH WINDS OR WINTER WEATHER SUCH AS ICE OR SNOW IS EXPECTED. IF INCLEMENT WEATHER ARISES, IT IS RECOMMENDED TO TURN LOUVERS INTO THE FULLY OPEN (UPRIGHT) POSITION. THIS WILL PREVENT DAMAGE TO THE STRUCTURE AND DECREASE THE CHANCES OF STRUCTURE OR LOUVER DAMAGE.**







**9205413**  
(x1) | **ELECTRICAL ENCLOSURE**

FOR POWERPORT INSTALLATION REFER TO ASSEMBLY INSTRUCTIONS THAT COME PACKAGED WITH THE POWERPORT KIT. INSTALL ON ANY EXTERIOR POST THAT IS DESIRED. FOLLOW DIRECTIONS FOR PROPER INSTALLATION.