



Manufactured by:  
Backyard Discovery  
3305 Airport Drive, Pittsburg, KS 66762  
800-856-4445

Basepoint Business Centre: Rivermead Drive, Westlea, Swindon SN5 7EX Phone: 0800-118-2476  
J.P. Coenstraat 7, The Bridge, The Hague, 2595 WP, Netherlands Phone: 08005678990

# LANCASTER L-SHAPE OUTDOOR KITCHEN

MODEL #: 2404144



**WARNING**

Cancer and Reproductive Harm  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)



Please visit [www.backyarddiscovery.com](http://www.backyarddiscovery.com)  
For the most up to date assembly manual, to register your product, or to order  
replacement parts Para obtener instrucciones en español, visite  
[www.backyarddiscovery.com](http://www.backyarddiscovery.com)



**EASY STEP-BY-STEP**  
3D INTERACTIVE INSTRUCTIONS  
DOWNLOAD THE FREE APP







# OWNER'S MANUAL - BASIC SETUP DIMENSIONS & ASSEMBLY NOTES

It is critically important that you start with square and level footings or concrete pad to attach your structure.

- Pay close attention to the items needed for each step. Make sure you are using the correct hardware for each step. Using incorrect hardware may result in improper assembly
- Remember to double check for underground utilities and overhead electrical lines


Post mounts are provided with your structure which allows you to permanently install your structure to a pre-existing or new wood or concrete surface. See Anchor Instructions for further details and recommendations.

- The hardware to attach the post mounts to the structure is included.
- The hardware to mount the structure permanently to a concrete surface is included.
- The hardware to mount the structure permanently to a wood deck is NOT included and will need to be purchased separately. You must ensure there is ample structural support under the deck before permanently attaching.




# OWNER'S MANUAL - ANCHORING LAYOUT

**NOTE: DIMENSIONS ARE TO ANCHOR PLATES MOUNTED TO POSTS EXCEPT WHERE NOTED.**




# OWNER'S MANUAL - PARTS IDENTIFICATION


## METAL COMPONENTS FOR PERGOLA (NOT TO SCALE)




**P01 FRONT POST - A4M03503**  
(x1) 89 9/16"x6 1/8"x4 3/4" (120x155x2275)



**P03 BACK POST - A4M03505**  
(x1) 89 9/16"x6 1/8"x4 3/4" (120x155x2275)



**P04 BACK POST - A4M03506**  
(x1) 89 9/16"x6 1/8"x4 3/4" (120x155x2275)



**P05 FRONT POST - A4M03646**  
(x1) 89 9/16"x6 1/8"x4 3/4" (120x155x2275)



**B03 FRONT BEAM ASSEMBLY - A4M03509**  
(x2) 78 3/16"x5 1/4"x1 7/16" (36x134x1986)



**B04 FRONT BEAM ASSEMBLY - A4M03510**  
(x2) 78 3/16"x5 1/4"x1 7/16" (36x134x1986)




**B05 FRONT BEAM ASSEMBLY - A4M03511**  
(x2) 72"x5 1/4"x1 7/16" (36x134x1829)



**B06 FRONT BEAM ASSEMBLY - A4M03512**  
(x2) 72"x5 1/4"x1 7/16" (36x134x1829)



**B17 SIDE BEAM ASSEMBLY - A4M03648**  
(x2) 64 15/16"x5 5/16"x1 7/16" (36x135.50x1649)



**B18 SIDE BEAM ASSEMBLY - A4M03649**  
(x2) 55 9/16"x5 1/4"x1 1/2" (37.50x134x1411)




**B07 GABLE ARM ASSEMBLY - A4M03513**  
(x2) 29 3/16"x5 1/4"x1 7/16" (36x134x741)

# OWNER'S MANUAL - PARTS IDENTIFICATION


METAL COMPONENTS FOR PERGOLA (NOT TO SCALE)



**B16 RIDGE BEAM ASSEMBLY - A4M03647**  
(x1) 92 15/16"x5 5/16"x1 9/16" (39x135.50x2361)



**B19 DRIP BEAM ASSEMBLY - A4M03650**  
(x2) 89 15/16"x4 13/16"x1 7/16" (36x122x2285)



**B12 GABLE BEAM ASSEMBLY - A4M03518**  
(x2) 88 13/16"x5 1/4"x1 7/16" (36x134x2255)



**B13 GABLE BEAM ASSEMBLY - A4M03519**  
(x2) 88 13/16"x5 1/4"x1 7/16" (36x134x2255)



**R01 RAFTER ASSEMBLY - A4M03522**  
(x2) 86 3/8"x4 5/16"x3 1/8" (80x110x2194.6)



**R02 RAFTER ASSEMBLY - A4M03523**  
(x2) 86 3/8"x4 5/16"x3 1/8" (80x110x2194.6)




**R03 RAFTER ASSEMBLY - A4M03524**  
(x4) 86 3/8"x4 5/16"x3 1/8" (80x110x2194.6)



**C01 CORBEL ASSEMBLY - A4M03525**  
(x4) 21 13/16"x5 1/4"x2 3/4" (70x134x553.5)



**C02 CORBEL ASSEMBLY - A4M03526**  
(x4) 21 13/16"x5 1/4"x2 3/4" (70x134x553.5)



**C03 CORBEL ASSEMBLY - A4M03527**  
(x2) 23 3/8"x12"x1 7/16" (36x304x593)



**E03 PURLIN ASSEMBLY - A4M03651**  
(x10) 89 15/16"x1 15/16"x1 9/16" (40x50x2284)



**B08 GABLE ARM ASSEMBLY - A4M03514**  
(x2) 40 1/16"x5 1/4"x1 7/16" (36x134x1017)



**B09 GABLE ARM ASSEMBLY - A4M03515**  
(x2) 40 1/16"x5 1/4"x1 7/16" (36x134x1017)



**J1 SPLICE BRACKET - A4M02230**  
(x4) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)

# OWNER'S MANUAL - PARTS IDENTIFICATION

## METAL COMPONENTS FOR PERGOLA (NOT TO SCALE)



**J3 GABLE BRACKET - A4M03805**  
(x2) 11 1/8"x6 7/16"x1/16" (2x163x282)



**J4 BEAM BRACKET - A4M02990**  
(x8) 1"x1 5/16"x5 1/16" (25x33.2x128)



**J5 RAFTER BRACKET - A4M03803**  
(x4) 3 5/8"x2 11/16"x2 1/16" (52x68x91.5)



**J7 RAFTER BRACKET - A4M03802**  
(x4) 3 5/8"x2 3/16"x2" (50x55x92)



**J8 GABLE BRACKET - A4M03804**  
(x4) 4 13/16"x1 9/16"x1 9/16" (40x40x123)



**J9 BEAM BRACKET - A4M03807**  
(x4) 1"x1 5/16"x4 9/16" (25x33.20x116)



**J10 SUPPORT RING - A4M03808**  
(x4) 13/16"x7/16" (11x20)



**A4M01352 HOLE COVER**  
(x70)



**A4M03528 STEEL SHEETING**  
(x10)




**A4M03653 DRIP TRIM**  
(x2)



**A4M03532 EDGE TRIM**  
(x4)



**A4M03652 RIDGE CAP**  
(x1)



**9205413 ELECTRICAL ENCLOSURE**  
(x1)

# OWNER'S MANUAL - PARTS IDENTIFICATION


## METAL COMPONENTS FOR CABINETS (NOT TO SCALE)



**S2 PIZZA OVEN CABINET SIDE PANEL ASSEMBLY M - A4M03545**  
(x1) 26 1/2"x23 3/8"x1 3/8" (35.00x593.00x673.50)




**S4 SINK CABINET SIDE PANEL ASSEMBLY R - A4M03563**  
(x1) 33 3/8"x23 3/8"x2 5/8" (67.00x594.00x848.20)




**S5 SINK CABINET SIDE PANEL ASSEMBLY M - A4M03567**  
(x1) 33 3/8"x23 3/8"x2 3/16" (56.20x593.00x847.00)



**S6 GRILL CABINET SIDE PANEL ASSEMBLY M - A4M03586**  
(x1) 23 3/8"x22 7/8"x1 3/8" (35.00x581.00x593.00)



**S7 FRIDGE CABINET SIDE PANEL ASSEMBLY L - A4M03597**  
(x1) 33 7/16"x23 3/8"x2 1/16" (53.00x594.00x849.70)




**S8 FRIDGE CABINET SIDE PANEL ASSEMBLY R - A4M03598**  
(x1) 33 3/8"x23 3/8"x1 15/16" (50.00x594.00x848.20)



**S13 CONNECT PANEL ASSEMBLY - A4M03673**  
(x1) 35 1/8"x23 3/8"x2 3/8"x2 3/8" (61.00x594.00x892.00)



**S14 PIZZA OVEN CABINET SIDE PANEL ASSEMBLY - A4M03657**  
(x1) 26 9/16"x23 3/8"x1 3/8" (35.00x594.00x675.00)



**S15 CORNER CABINET SIDE PANEL ASSEMBLY M - A4M03675**  
(x1) 33 7/16"x23 3/8"x6 1/16" (154.10x593.00x848.70)




**S18 SINK CABINET SIDE PANEL ASSEMBLY L - A4M03705**  
(x1) 33 3/8"x23 3/8"x2 1/2" (62.90x594.00x848.20)

# OWNER'S MANUAL - PARTS IDENTIFICATION


## METAL COMPONENTS FOR CABINETS (NOT TO SCALE)




**T1 PIZZA OVEN CABINET TABLETOP ASSEMBLY - A4M03543**  
(x1) 40 3/16"x23 3/8"x1 1/4" (32x594x1020)




**T2 GRILL TABLETOP ASSEMBLY - A4M03057**  
(x1) 1 1/4"x23 3/8"x38 3/16" (32x594x970)




**T3 PIZZA OVEN CABINET MARBLE PANEL ASSEMBLY R - A4M03551**  
(x1) 612.00x4 5/16"x6 3/4" (172.20x109.00x612.00)




**T4 SINK CABINET TABLETOP FRAME - A4M03566**  
(x1) 37 3/16"x24 1/8"x1 1/4" (32x612x944)




**T7 FRIDGE CABINET TABLETOP - A4M03641**  
(x1) 27 3/8"x24 1/8"x1 1/4" (32x612x696)




**T10 PIZZA OVEN CABINET MARBLE PANEL ASSEMBLY L - A4M03662**  
(x1) 24 1/8"x4 5/16"x6 3/4" (172.20x109.00x612.00)



**T11 CORNER CABINET TOPTABLE ASSEMBLY - A4M03670**  
(x1) 40 3/16"x24 1/8"x1 1/4" (32.00x612.00x1020.00)



**L2 GRILL CABINET SHELF ASSEMBLY - A4M03589**  
(x1) 23 1/4"x18 3/8"x1" (25.00x467.00x591.00)



**L5 PIZZA OVEN CABINET SHEFT - A4M03661**  
(x1) 23 1/4"x19 1/4"x1" (25.00x489.50x591.00)




**L6 CORNER CABINET SHEFT ASSEMBLY - A4M03680**  
(x1) 25 5/8"x23 3/16"x1" (25.00x589.00x650.40)




# OWNER'S MANUAL - PARTS IDENTIFICATION


## METAL COMPONENTS FOR CABINETS (NOT TO SCALE)



**D3 SINK CABINET DRAWER PANEL ASSEMBLY - A4M03569**  
(x1) 17 3/4"x10 1/4"x15/16" (24.00x260.00x451.00)



**D4 SINK CABINET DRAWER BODY FRAME - A4M03571**  
(x1) 22 1/4"x16 1/16"x6 7/16" (164.20x408.40x565.40)



**D5 SINK CABINET TRIM PANEL ASSEMBLY - A4M03576**  
(x1) 17 13/16"x10 1/4"x1" (26.00x260.00x452.00)




**D6 SINK CABINET DOOR ASSEMBLY L - A4M03577**  
(x1) 22 1/4"x17 13/16"x15/16" (24.00x452.00x565.00)



**D7 GRILL CABINET DOOR ASSEMBLY L - A4M03587**  
(x1) 24 13/16"x19 1/16"x15/16" (24.00x484.15x630.00)




**D8 GRILL CABINET DOOR ASSEMBLY R - A4M03590**  
(x1) 24 13/16"x19 1/16"x15/16" (24.00x484.15x630.00)




**D9 TRASH CAN PANEL ASSEMBLY - A4M03608**  
(x1) 22 1/4"x17 3/4"x15/16" (24.00x451.00x565.00)



**D14 PIZZA OVEN CABINET DOOR ASSEMBLY L - A4M03659**  
(x1) 28 7/16"x18 7/8"x15/16" (24.00x480.00x722.50)



**D15 PIZZA OVEN CABINET DOOR ASSEMBLY - A4M03664**  
(x1) 28 7/16"x18 7/8"x15/16" (24.00x480.00x722.50)



**D16 SPICE BASKET - A4M03683**  
(x1) 33 3/16"x79.80x13 3/4" (348.90x481.00x843.20)

# OWNER'S MANUAL - PARTS IDENTIFICATION


## METAL COMPONENTS FOR CABINETS (NOT TO SCALE)




**D17 CORNER CABINET DOOR ASSEMBLY - A4M03682**  
(x1) 33 7/8"x18 1/4"x15/16" (23.20x463x860.40)




**G3 SINK CABINET BACK PANEL ASSEMBLY - A4M03564**  
(x1) 34 5/16"x33 3/8"x1 3/16" (30.00x847.20x872.00)




**G4 FRIDGE CABINET BACK PANEL ASSEMBLY - A4M03599**  
(x1) 25 5/16"x33 3/8"x1 3/16" (30.00x847.20x643.00)




**G8 PIZZA OVEN CABINET BACK PANEL ASSEMBLY - A4M03658**  
(x1) 38 3/4"x26 1/2"x1 3/16" (30.00x673.50x984.00)




**G9 CORNER CABINET BACK PANEL ASSEMBLY - A4M03669**  
(x1) 38 3/4"x33 7/16"x1 3/16" (30.00x848.70x984.00)



**G10 GRILL CABINET BACK PANEL ASSEMBLY - A4M03055**  
(x1) 1 3/16"x22 7/8"x38 3/16" (30x581x970)



**G11 GRILL VENTILATION PANEL - A4M03056**  
(x1) 1 5/16"x11 3/16"x38 3/16" (33x284x970)



**O8 PIZZA OVEN VENTILATION PANEL - A4M03078**  
(x1) 1 3/16"x3 3/4"x31 7/16" (30x95x799)




**A4 SLIDE BRACKET ASSEMBLY - A4M03709**  
(x2) 18 7/8"x3 1/8"x1 1/16" (27.20x80.00x480.00)




**A7 TRIANGLE BRACKET - A4M03708**  
(x2) 5 7/8"x5 7/8"x9/16" (15.00x150.00x150.00)

# OWNER'S MANUAL - PARTS IDENTIFICATION


## METAL COMPONENTS FOR CABINETS (NOT TO SCALE)




**F1 PIZZA OVEN CABINET FLOOR PANEL ASSEMBLY - A4M03538**  
(x1) 40 3/16"x23 3/8"x2 5/8" (66x594x1020)




**F2 GRILL CABINET FLOOR PANEL ASSEMBLY - A4M03048**  
(x1) 2 5/8"x23 3/8"x38 1/4" (66x594x972)



**F3 SINK CABINET FLOOR PANEL ASSEMBLY - A4M03560**  
(x1) 37 3/16"x23 3/8"x2 5/8" (66x594x944)




**F4 FRIDGE CABINET FLOOR PANEL ASSEMBLY - A4M03595**  
(x1) 28 1/8"x23 3/8"x2 5/8" (66x594x715)




**F6 CORNER CABINET FLOOR PANEL ASSEMBLY - A4M03667**  
(x1) 40 3/16"x23 7/16"x2 5/8" (66x595.50x1020)



**9240162 OUTDOOR KITCHEN FRIDGE - RIGHT OPEN**  
(x1)




**9240025 OUTDOOR KITCHEN GRILL KIT**  
(x1)




**9240018 OUTDOOR KITCHEN PIZZA OVEN**  
(x1)

# OWNER'S MANUAL - PARTS IDENTIFICATION


## METAL COMPONENTS FOR CABINETS (NOT TO SCALE)




**M1 PIZZA OVEN CABINET MARBLE - A4M03553**  
(x1) 24 13/16"x4 5/16"x1 15/16" (50.00x109.00x630.00)



**M3 FRIDGE CABINET MARBLE - A4M03602**  
(x1) 28 1/8"x24 15/16"x1 15/16" (50x634x715)




**M5 SINK COVER MARBLE - A4M03147**  
(x1) 11/16"x14 3/4"x16 5/16" (18x375x415)




**M7 SINK CABINET MARBLE - A4M03655**  
(x1) 37 3/16"x24 15/16"x1 15/16" (50x634x944)




**M8 PIZZA OVEN CABINET MARBLE R - A4M03666**  
(x1) 24 15/16"x4 5/16"x1 15/16" (50.00x109.00x634.00)



**M9 CORNEER CABINET MARBLE - A4M03671**  
(x1) 40 3/16"x24 15/16"x1 15/16" (50x634x1020)



**H2 STAINLESS STEEL HANDLE - A4M03024**  
(x9) 5/8"x1 9/16"x11 13/16" (16x40x300)



**H3 TRASH CAN BRACKET ASSEMBLY - A4M03610**  
(x1) 1 3/8"x18 1/16"x15 13/16" (35.00x401.60x458.00)



**H4 HORIZONTAL BEAM ASSEMBLY L - A4M03575**  
(x4) 16 1/4"x3 3/8"x1" (25.00x85.00x413.00)



**H8 CORNER CABINET HORIZONTAL BEAM ASSEMBLY - A4M03672**  
(x1) 12 15/16"x3"x1" (25.00x76.50x328.80)



**H9 CORNER CABINET BRACKET ASSEMBLY - A4M03681**  
(x1) 33 7/16"x4 3/4"x1 3/8" (35.00x120.00x848.70)




**H10 PIZZA OVEN CABINET HINGE CHANNEL ASSEMBLY - A4M03686**  
(x1) 26 9/16"x2 15/16"x2 1/8" (54.00x74.80x674.00)

# OWNER'S MANUAL - PARTS IDENTIFICATION


## METAL COMPONENTS FOR CABINETS (NOT TO SCALE)




**A2 MAGNET BRACKET - A4M03026**  
(x5) 1"x1 1/4"x3 1/8" (25x31x80)



**A8 MAGNET BRACKET - A4M03715**  
(x1) 3 1/8"x2 3/16"x1" (25.00x56.30x80.00)




**A5 SHELF BRACKET - A4M03141**  
(x4) 5/8"x7/8"x2 1/16" (16x22x53)



**A6 ANGLED BRACKET - A4M03053**  
(x4) 1 3/8"x1 15/16"x17 1/8" (35x50x435)




**A9 HOSE BRACKET ASSEMBLY - A4M03060**  
(x2) 1 1/4"x1 7/16"x2 9/16" (31.5x36.5x65)




**A12 DOOR STOPPER - A4M04128**  
(x1) 3 11/16"x1 3/4"x1/2" (13.30x45.00x94.00)




**A11 TRIANGLE PANEL - A4M03086**  
(x2) 13/16"x13 3/4"x13 3/4" (20x350x350)




**A13 GAS TANK HOLDER ASSEMBLY - A4M03047**  
(x2) 1 15/16"x12 7/8"x14 3/4" (49x327x374)



**A16 SINK ASSEMBLY - A4M03143**  
(x1) 15 1/8"x15 5/16"x16 7/8" (384x389x429)



**A4M02290 MAGNETIC PAPER TOWEL HOLDER**  
(x2)




**A4M03025 FULL OVERLAY HINGE**  
(x10)




**A4M03151 GARDEN HOSE ADAPTER**  
(x1)

# OWNER'S MANUAL - PARTS IDENTIFICATION


## HARDWARE COMPONENTS




**H101202 | TORX PAN HEAD**  
(x392) | 1/4-20x3/4 ASSY




**H101117 | SCREW WOODGRIP**  
(x100) | 10-16 x 3/4 BLK




**H101116 | SCREW SELF TAPPING**  
(x34) | 1/4x1 BLK




**H101132 | TORX SOCKET SCREW SHORT**  
(x40) | 1/4-20 BLK




**H101103 | TORX SOCKET SCREW**  
(x116) | 1/4-20 BLK




**H101230 | BOLT WH**  
(x2) | 5/16x6 S.S BLK



**H101278 | MAGNETIC DRIVER EXTENSION**  
(x1) |




**H100147 | TORX BIT**  
(x1) | T-30



**H101100 | MAGNETIC DRIVER**  
(x1) |




**H100114 | TORX BIT**  
(x1) | T-30



**H101292 | TORX PAN HEAD**  
(x24) | 1/4-20x13/32" BLK




**H101185 | PHILLIPS FLAT HEAD**  
(x60) | 8-32x.5 BLK



**H101289 | PAN HEAD SCREW**  
(x73) | 8-32x1/2" SS BLK




**H101309 | PAN HEAD SCREW**  
(x6) | 8-32x2 1/2" SS BLK




**H101307 | SHOULDER BOLT**  
(x16) | 8-32x30mm SS BLK




**H101293 | TORX PAN HEAD**  
(x4) | 1/4-20x1 3/8" BLK




**H100120 | CONCRETE ANCHOR**  
(x8) | 1/4"x2" BLK




**H101053 | STEEL WASHER**  
(x20) | 6x20 BLK




**H101054 | SEALANT WASHER**  
(x20) | 6.5x18 BLK




**H100630 | WASHER FLAT**  
(x8) | 8x19 BLK



**H101106 | SOCKET DRIVER**  
(x1) |



**H101294 | HEX DRIVER**  
(x1) |



**H101114 | RIGHT ANGLE DRILL ADAPTER**  
(x1) |

# PRE-ASSEMBLY STEP 1 - SORTING PARTS


It is critical for ease of assembly that you take the time to sort and organize the parts and hardware.

---

## METAL PARTS:

- Organize metal parts by the three-digit, alpha-numeric number stamped on each part (ex. P01).
- If there are multiple parts with the same stamped number, stack those pieces together.
- Stamps can be found on the flat surface of the parts or on the end of the parts.
- Allow yourself plenty of room - the parts can take up a significant amount of space.

**NOTE: CARTONS ARE NOT ORGANIZED BY PART OR STEP NUMBER.**



## HARDWARE PARTS:

- We recommend that you have a separate table to organize the hardware.
- Hardware bags are printed with a seven-digit, alpha-numeric part number.
- You can organize your hardware by part number or group by hardware type (e.g. bolts, nuts, etc.).
- During assembly you only need to reference the last four digits of the number.



# PRE-ASSEMBLY STEP 2 - TOOLS REQUIRED



Cordless Drill or  
Electric Drill




Drill Attachments:  
Phillips Head



1/8", 3/16", 3/8" &  
7/16" Drill Bits



Phillips Screw Driver



Open End Wrench  
7/16"



3/8" Drive Ratchet, 1/2" &  
7/16" STD Sockets 1/2" & 7/16"  
Deep Sockets




Claw Hammer



Rubber Mallet -  
Optional



Tape Measure



Square




Level 24"



# PRE-ASSEMBLY STEP 3 - CHOOSE YOUR ASSEMBLY METHOD

There are several types of assembly instructions available to you.

1. Printed Assembly Manual included with your set
2. BILT APP - 3D interactive instructions
3. Combination of the Printed Manual and BILT APP (Note: Step numbers can differ between the two methods)




**BILT.**<sup>®</sup>

Scan for easy  
**3D instructions**

Download the BILT app  
before you begin

Download on the  
App Store

GET IT ON  
Google Play



Hardware Needed

17

< || >

The image is a promotional graphic for the BILT app. It features the BILT logo at the top left, a QR code at the top right, and the text 'Scan for easy 3D instructions' in a large, bold font. Below this, it says 'Download the BILT app before you begin'. There are two buttons for downloading the app: 'Download on the App Store' and 'GET IT ON Google Play'. At the bottom, there is a smartphone displaying a 3D assembly instruction screen. The screen shows a 3D model of a structure with a horizontal beam and a triangular support. The screen has a 'Hardware Needed' button at the top left, a close button (X) at the top right, a menu button (three dots) and a back button (left arrow) on the right side, and a page number '17' at the bottom left. At the bottom center of the screen, there are navigation buttons: a left arrow, a play/pause button (two vertical bars), and a right arrow.

# STEP 1 - BEAM ASSEMBLY

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




**B04 FRONT BEAM ASSEMBLY - A4M03510**  
 (x1) 78 3/16"x5 1/4"x1 7/16" (36x134x1986)



**J1 SPLICE BRACKET - A4M02230**  
 (x1) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)

- FOR EASE OF ASSEMBLY, WE RECOMMEND USING SAW HORSES FOR STEPS 1 - 12.



**BEAM AND SPLICE MUST BE ORIENTED AS SHOWN ABOVE. SLIDE J1 INTO B04 AND LINE UP THREE HOLES TOP AND BOTTOM**


# STEP 2 - BEAM ASSEMBLY

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



**B03 FRONT BEAM ASSEMBLY - A4M03509**  
(x1) 78 3/16"x5 1/4"x1 7/16" (36x134x1986)

- SLIDE B03 INTO SPLICE BRACKET.  
GENTLY TAP ENDS OF ASSEMBLY WITH  
RUBBER Mallet UNTIL GAP CLOSES.



# STEP 3 - BEAM ASSEMBLY

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




**B06 FRONT BEAM ASSEMBLY - A4M03512**  
 (x1) 72"x5 1/4"x1 7/16" (36x134x1829)



**J1 SPLICE BRACKET - A4M02230**  
 (x1) 1 5/16"x5 3/16"x39 3/8" (33.2x131.2x1000)


1202 (x6)  
 TORX PAN HEAD 1/4-20x3/4 ASSY



**HAND TIGHTEN ONLY**

J1 (x1)  
 SPLICE BRACKET

B06 (x1)  
 FRONT BEAM ASSEMBLY



**BEAM AND SPLICE MUST BE ORIENTED AS SHOWN ABOVE. SLIDE J1 INTO B06 AND LINE UP THREE HOLES TOP AND BOTTOM**


# STEP 4 - BEAM ASSEMBLY

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




**B05 FRONT BEAM ASSEMBLY - A4M03511**  
(x1) 72"x5 1/4"x1 7/16" (36x134x1829)

- SLIDE B05 INTO SPLICE BRACKET.  
GENTLY TAP ENDS OF ASSEMBLY WITH  
RUBBER Mallet UNTIL GAP CLOSES.



**1202 (x6)**  
**TORX PAN HEAD 1/4-20x3/4 ASSY**

**TIGHTEN ALL HARDWARE**




**B05 (x1)**  
**FRONT BEAM ASSEMBLY**


**ALL THREADED INSERTS  
WILL BE ON THE SAME SIDE  
OF THE BEAM**

# STEP 5 - BEAM ASSEMBLY

Qty	PartNo	Description
4	H101103	TORX SOCKET SCREW 1/4-20




UPPER BEAM ASSEMBLY STEPS 1 - 2



LOWER BEAM ASSEMBLY STEPS 3 - 4

- ALIGN THRU HOLES IN LOWER BEAM ASSEMBLY WITH THREADED INSERTS IN UPPER BEAM ASSEMBLY




1103(x4)  
TORX SOCKET SCREW 1/4-20

UPPER BEAM ASSEMBLY

LOWER BEAM ASSEMBLY

FRONT VIEW




**DIMENSIONS ARE THE SAME AT BOTH ENDS AND CRITICAL TO THE BEAM ASSEMBLY**

**REPEAT BEAM ASSEMBLY  
STEPS 1 THROUGH 5**

# STEP 6 - POST ASSEMBLY


Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



**P03 BACK POST - A4M03505**  
(x1) 89 9/16"x6 1/8"x4 3/4" (120x155x2275)




**J4 BEAM BRACKET - A4M02990**  
(x2) 1"x1 5/16"x5 1/16" (25x33.2x128)





# STEP 7 - POST ASSEMBLY


Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



**P04 BACK POST - A4M03506**  
(x1) 89 9/16"x6 1/8"x4 3/4" (120x155x2275)



**J4 BEAM BRACKET - A4M02990**  
(x2) 1"x1 5/16"x5 1/16" (25x33.2x128)





# STEP 8A - FRAME ASSEMBLY



BEAM ASSEMBLY FROM STEPS 1 - 5

- SLIDE EACH POST ASSEMBLY INTO THE BEAM ASSEMBLY FROM STEPS 1 - 5.




# STEP 8B - FRAME ASSEMBLY

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

1202 (x4)  
TORX PAN HEAD 1/4-20x3/4 ASSY

**HAND TIGHTEN ONLY**



# STEP 8C - FRAME ASSEMBLY

Qty	PartNo	Description
8	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




**C01 CORBEL ASSEMBLY - A4M03525**  
 (x1) 21 13/16"x5 1/4"x2 3/4" (70x134x553.5)



**C02 CORBEL ASSEMBLY - A4M03526**  
 (x1) 21 13/16"x5 1/4"x2 3/4" (70x134x553.5)


- ATTACH CORBELS TO BEAM AND POST.
- SQUARE AS NEEDED BEFORE TIGHTENING ALL HARDWARE FROM PREVIOUS STEPS.



# STEP 8D - FRAME ASSEMBLY

Qty	PartNo	Description
8	H101103	TORX SOCKET SCREW 1/4-20

- WITH AN ADDITIONAL PERSON, FLIP POST AND BEAM ASSEMBLY



# STEP 9 - BEAM ASSEMBLY

Qty	PartNo	Description
3	H101103	TORX SOCKET SCREW 1/4-20





**B17 SIDE BEAM ASSEMBLY - A4M03648**  
 (x1) 64 15/16"x5 5/16"x1 7/16" (36x135.50x1649)




**B18 SIDE BEAM ASSEMBLY - A4M03649**  
 (x1) 55 9/16"x5 1/4"x1 1/2" (37.50x134x1411)

- ALIGN THRU HOLES IN B18 BEAM WITH THREADED INSERTS IN B17 BEAM.




**DIMENSIONS ARE THE SAME AT BOTH ENDS AND CRITICAL TO THE BEAM ASSEMBLY**

# STEP 10 - BEAM ASSEMBLY



Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

J5 RAFTER BRACKET - A4M03803  
(x2) 3 5/8"x2 11/16"x2 1/16" (52x68x91.5)




**REPEAT BEAM ASSEMBLY  
STEPS 9 THROUGH 10**



# STEP 11 - POST ASSEMBLY


Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




P05 FRONT POST - A4M03646  
(x1) 89 9/16"x6 1/8"x4 3/4" (120x155x2275)



J4 BEAM BRACKET - A4M02990  
(x2) 1"x1 5/16"x5 1/16" (25x33.2x128)





# STEP 12A - FRAME ASSEMBLY




BEAM ASSEMBLY FROM STEPS 9 - 10

- SLIDE POST ASSEMBLY FROM STEP 11 INTO THE BEAM ASSEMBLY FROM STEPS 9 - 10.



# STEP 12B - FRAME ASSEMBLY

Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



# STEP 12C - FRAME ASSEMBLY




Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY


C01 CORBEL ASSEMBLY - A4M03525  
 (x1) 21 13/16"x5 1/4"x2 3/4" (70x134x553.5)

- ATTACH CORBEL TO BEAM AND POST.
- SQUARE AS NEEDED BEFORE TIGHTENING ALL HARDWARE FROM PREVIOUS STEPS.

1202 (x4)  
 TORX PAN HEAD 1/4-20x3/4 ASSY




C01 (x1)  
 CORBEL ASSEMBLY



# STEP 12D - FRAME ASSEMBLY



Qty	PartNo	Description
4	H101103	TORX SOCKET SCREW 1/4-20

- WITH AN ADDITIONAL PERSON, FLIP POST AND BEAM ASSEMBLY




# STEP 13A - FRAME ASSEMBLY

- WITH AT LEAST THREE OTHER PEOPLE, ATTACH BEAM AND POST ASSEMBLIES BY SLIDING IN PLACE.



# STEP 13B - FRAME ASSEMBLY

Qty	PartNo	Description
4	H101103	TORX SOCKET SCREW 1/4-20




# STEP 13C - FRAME ASSEMBLY

Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- SQUARE BEAM ASSEMBLY TO POST

1202 (x2)  
TORX PAN HEAD 1/4-20x3/4 ASSY

TIGHTEN ALL HARDWARE






# STEP 14 - FRAME ASSEMBLY

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




C02 CORBEL ASSEMBLY - A4M03526  
(x1) 21 13/16"x5 1/4"x2 3/4" (70x134x553.5)

- ATTACH CORBEL TO BEAM AND POST.
- SQUARE AS NEEDED BEFORE TIGHTENING ALL HARDWARE.



1202 (x4)  
TORX PAN HEAD  
1/4-20x3/4 ASSY


CORBEL BRACKET HOLES  
WILL FIT AROUND THREADED  
INSERTS AND FLUSH AGAINST  
BEAM AND POST



C02 (x1)  
CORBEL  
ASSEMBLY

# STEP 15 - POST ASSEMBLY

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




P01 FRONT POST - A4M03503  
(x1) 89 9/16"x6 1/8"x4 3/4" (120x155x2275)




J4 BEAM BRACKET - A4M02990  
(x2) 1"x1 5/16"x5 1/16" (25x33.2x128)

- FOR EASE OF ASSEMBLY, WE RECOMMEND USING SAW HORSES FOR STEPS 15 - 16.





# STEP 16A - FRAME ASSEMBLY



BEAM ASSEMBLY FROM STEPS 9 - 10


- SLIDE POST ASSEMBLY FROM STEP 15 INTO THE BEAM ASSEMBLY FROM STEPS 9 - 10.



# STEP 16B - FRAME ASSEMBLY

Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

1202 (x2)  
TORX PAN HEAD 1/4-20x3/4 ASSY  
**HAND TIGHTEN ONLY**




# STEP 16C - FRAME ASSEMBLY

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




C02 CORBEL ASSEMBLY - A4M03526  
(x1) 21 13/16"x5 1/4"x2 3/4" (70x134x553.5)

- ATTACH CORBEL TO BEAM AND POST.
- SQUARE AS NEEDED BEFORE TIGHTENING ALL HARDWARE FROM PREVIOUS STEPS.



1202 (x4)  
TORX PAN HEAD 1/4-20x3/4 ASSY


C02 (x1)  
CORBEL ASSEMBLY



# STEP 16D - FRAME ASSEMBLY


Qty	PartNo	Description
4	H101103	TORX SOCKET SCREW 1/4-20

- WITH AN ADDITIONAL PERSON, FLIP POST AND BEAM ASSEMBLY




# STEP 17A - FRAME ASSEMBLY

- WITH AT LEAST TWO OTHER PEOPLE, ATTACH BEAM AND POST ASSEMBLIES BY SLIDING IN PLACE.




BEAM AND POST  
ASSEMBLY STEPS 15 - 16



# STEP 17B - FRAME ASSEMBLY

Qty	PartNo	Description
4	H101103	TORX SOCKET SCREW 1/4-20






# STEP 17C - FRAME ASSEMBLY


Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- SQUARE BEAM ASSEMBLY TO POST



1202 (x2)  
TORX PAN HEAD 1/4-20x3/4 ASSY

**TIGHTEN ALL HARDWARE**




# STEP 18 - FRAME ASSEMBLY

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




C01 CORBEL ASSEMBLY - A4M03525  
(x1) 21 13/16"x5 1/4"x2 3/4" (70x134x553.5)

- ATTACH CORBEL TO BEAM AND POST.
- SQUARE AS NEEDED BEFORE TIGHTENING ALL HARDWARE.




1202 (x4)  
TORX PAN HEAD 1/4-20x3/4 ASSY

**CORBEL BRACKET HOLES  
WILL FIT AROUND THREADED  
INSERTS AND FLUSH AGAINST  
BEAM AND POST**




C01 (x1)  
CORBEL ASSEMBLY

## STEP 19A - FRAME ASSEMBLY




BEAM ASSEMBLY FROM STEPS 1 - 5

- WITH AT LEAST TWO OTHER PEOPLE, SPREAD FRONT POST APART ENOUGH TO ATTACH BEAM ASSEMBLY INTO BEAM BRACKETS.



# STEP 19B - FRAME ASSEMBLY

Qty	PartNo	Description
8	H101103	TORX SOCKET SCREW 1/4-20





# STEP 19C - FRAME ASSEMBLY

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

**- SQUARE BEAM ASSEMBLY TO POST**

1202 (x4)  
TORX PAN HEAD 1/4-20x3/4 ASSY

**TIGHTEN ALL HARDWARE**



# STEP 20 - FRAME ASSEMBLY

Qty	PartNo	Description
8	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




C01 CORBEL ASSEMBLY - A4M03525  
(x1) 21 13/16"x5 1/4"x2 3/4" (70x134x553.5)




C02 CORBEL ASSEMBLY - A4M03526  
(x1) 21 13/16"x5 1/4"x2 3/4" (70x134x553.5)

- ATTACH CORBELS TO BEAM AND POST.
- SQUARE AS NEEDED BEFORE TIGHTENING ALL HARDWARE FROM PREVIOUS STEPS.

1202 (x8)  
TORX PAN HEAD 1/4-20x3/4 ASSY



CORBEL BRACKET HOLES  
WILL FIT AROUND THREADED  
INSERTS AND FLUSH AGAINST  
BEAM AND POST



C02 (x1)  
CORBEL ASSEMBLY


C01 (x1)  
CORBEL ASSEMBLY

# STEP 21 - SQUARE STRUCTURE

**CRITICAL:**

- SQUARE UNIT BEFORE PROCEEDING TO NEXT STEPS.
- THE BELOW DIMENSIONS ARE CRITICAL TO THE FINAL ASSEMBLY.
- MEASUREMENTS SHOULD BE WITHIN +/- 1/4" (6mm).
- MEASUREMENTS OUTSIDE OF TOLERANCE WILL LEAD TO ISSUES ON FUTURE ASSEMBLY STEPS.
- TIGHTEN ALL HARDWARE FROM PREVIOUS STEPS.

MEASUREMENTS TAKEN FROM INSIDE CORNER TO INSIDE CORNER OF POST




# STEP 22 - GABLE ASSEMBLY

Qty	PartNo	Description
8	H101103	TORX SOCKET SCREW 1/4-20




**B07 GABLE ARM ASSEMBLY - A4M03513**  
(x2) 29 3/16"x5 1/4"x1 7/16" (36x134x741)

**1103 (x8)**  
**TORX SOCKET SCREW 1/4-20**



**THREADED INSERTS WILL FACE TOWARD EACH OTHER ON GABLE ARMS**

**B07 (x2)**  
**GABLE ARM ASSEMBLY**






# STEP 23 - RIDGE BEAM ASSEMBLY


Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



**B16 RIDGE BEAM ASSEMBLY - A4M03647**  
 (x1) 92 15/16"x5 5/16"x1 9/16" (39x135.50x2361)




**J3 GABLE BRACKET - A4M03805**  
 (x2) 11 1/8"x6 7/16"x1/16" (2x163x282)




# STEP 24 - RIDGE ASSEMBLY

Qty	PartNo	Description
2	H101230	BOLT WH 5/16x6 S.S.




RIDGE BEAM ASSEMBLY STEP - 23

- WITH AT LEAST TWO PEOPLE, ATTACH RIDGE ASSEMBLY TO GABLE UPRIGHTS.
- RIDGE BEAM ASSEMBLY MUST BE ORIENTED AS SHOWN BELOW WITH LONG OVERHANG TOWARD THE FRONT



# STEP 25 - RIDGE ASSEMBLY



C03 CORBEL ASSEMBLY - A4M03527  
(x2) 23 3/8"x12"x1 7/16" (36x304x593)


Qty	PartNo	Description
8	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- IT IS RECOMMENDED TO USE PROVIDED ANGLE DRIVER TO INSTALL
- ATTACH CORBELS TO RIDGE BEAM AND GABLE ARMS.
- SQUARE AS NEEDED BEFORE TIGHTENING ALL HARDWARE FROM PREVIOUS STEPS.

1202 (x8)  
TORX PAN HEAD 1/4-20x3/4 ASSY


**TIGHTEN ALL HARDWARE**

**CORBEL BRACKET HOLES  
WILL FIT AROUND THREADED  
INSERTS AND FLUSH AGAINST  
RIDGE BEAM AND GABLE**



# STEP 26 - RIDGE ASSEMBLY

Qty	PartNo	Description
4	H101054	SEALANT WASHER
4	H101053	STEEL WASHER 6x20
4	H101293	TORX PAN HEAD 1/4-20x1 3/8"




A4M03652 RIDGE CAP  
(x1)



J10 SUPPORT RING - A4M03808  
(x4) 13/16"x7/16" (11x20)

- REMOVE PROTECTIVE FILM.
- ORIENT RIDGE CAP AS SHOWN BELOW.
- **WARNING: GLOVES ARE RECOMMENDED WHEN HANDLING STEEL ROOF PIECE.**

**FLUSH END OF RIDGE CAP WITH RIDGE PLATE**



# STEP 27 - ROOF ASSEMBLY



Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY


J7 RAFTER BRACKET - A4M03802  
(x4) 3 5/8"x2 3/16"x2" (50x55x92)

1202 (x4)  
TORX PAN HEAD  
1/4-20x3/4 ASSY

**HAND TIGHTEN ONLY.**

**BRACKET HOLES  
WILL FIT AROUND  
THREADED INSERTS**

J7 (x4)  
RAFTER BRACKET



# STEP 28 - ROOF ASSEMBLY

Qty	PartNo	Description
16	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



R01 RAFTER ASSEMBLY - A4M03522  
(x2) 86 3/8"x4 5/16"x3 1/8" (80x110x2194.6)



R02 RAFTER ASSEMBLY - A4M03523  
(x2) 86 3/8"x4 5/16"x3 1/8" (80x110x2194.6)

- INSERTS ON THE SIDE OF EACH RAFTER MUST FACE TOWARD THE INSIDE OF THE STRUCTURE.
- ATTACH EACH RAFTER AT THE RIDGE AS SHOWN BELOW.
- ONCE SUPPORTED, ATTACH END OF RAFTER TO RAFTER BRACKETS AT TOP OF EACH POST.

BRACKET HOLES WILL FIT AROUND THREADED INSERTS

BRACKET HOLES WILL FIT AROUND THREADED INSERTS

1202 (x8)  
TORX PAN HEAD  
1/4-20x3/4 ASSY

HAND TIGHTEN ONLY.

1202 (x8)  
TORX PAN HEAD  
1/4-20x3/4 ASSY

HAND TIGHTEN ONLY.

R02 (x1)  
RAFTER  
ASSEMBLY

THREADED INSERTS  
NEED TO FACE  
TOWARD THE INSIDE


FRONT

R01 (x1)  
RAFTER  
ASSEMBLY

R01 (x1)  
RAFTER  
ASSEMBLY

R02 (x1)  
RAFTER  
ASSEMBLY

BACK



# STEP 29 - ROOF ASSEMBLY

Qty	PartNo	Description
16	H101103	TORX SOCKET SCREW 1/4-20



**B08 GABLE ARM ASSEMBLY - A4M03514**  
(x2) 40 1/16"x5 1/4"x1 7/16" (36x134x1017)



**B09 GABLE ARM ASSEMBLY - A4M03515**  
(x2) 40 1/16"x5 1/4"x1 7/16" (36x134x1017)

**FLUSH TOP SURFACE  
OF GABLE AND RAFTER**

**1103 (x8)  
TORX SOCKET  
SCREW 1/4-20**

**HAND TIGHTEN ONLY.**

**1103 (x8)  
TORX SOCKET  
SCREW 1/4-20**

**BACK**

**B09 (x1)  
GABLE ARM  
ASSEMBLY**

**B08 (x1)  
GABLE ARM  
ASSEMBLY**


**B08 (x1)  
GABLE ARM  
ASSEMBLY**

**B09 (x1)  
GABLE ARM  
ASSEMBLY**

**FRONT**

# STEP 30A - ROOF ASSEMBLY

Qty	PartNo	Description
8	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




R03 RAFTER ASSEMBLY - A4M03524  
(x4) 86 3/8"x4 5/16"x3 1/8" (80x110x2194.6)

- ATTACH EACH RAFTER AT THE RIDGE AS SHOWN BELOW.


**BRACKET HOLES  
WILL FIT AROUND  
THREADED INSERTS**

1202 (x8)  
TORX PAN HEAD  
1/4-20x3/4 ASSY

**HAND TIGHTEN ONLY**



R03 (x4)  
RAFTER ASSEMBLY






# STEP 30B - ROOF ASSEMBLY


Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- ATTACH END OF EACH RAFTER TO BRACKETS ALONG SIDE BEAMS.




# STEP 31 - ROOF ASSEMBLY

Qty	PartNo	Description
16	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




B19 DRIP BEAM ASSEMBLY - A4M03650  
(x2) 89 15/16"x4 13/16"x1 7/16" (36x122x2285)

- WITH AT LEAST TWO ADDITIONAL PEOPLE, ATTACH BEAM ASSEMBLY TO RAFTER ENDS.
- BEAM ASSEMBLY MUST BE ORIENTED AS SHOWN BELOW WITH LONG OVERHANG TOWARD THE FRONT




# STEP 32 - ROOF ASSEMBLY

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




**B13 GABLE BEAM ASSEMBLY - A4M03519**  
(x2) 88 13/16"x5 1/4"x1 7/16" (36x134x2255)



**J9 BEAM BRACKET - A4M03807**  
(x2) 1"x1 5/16"x4 9/16" (25x33.20x116)

**- REPEAT THIS STEP TWICE**




# STEP 33 - ROOF ASSEMBLY



Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

J8 GABLE BRACKET - A4M03804  
 (x2) 4 13/16"x1 9/16"x1 9/16" (40x40x123)

- REPEAT THIS STEP TWICE



# STEP 34A - ROOF ASSEMBLY

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY





GABLE BEAM ASSEMBLY FROM STEPS 32 - 33

- WITH AT LEAST TWO ADDITIONAL PEOPLE, ATTACH GABLE BEAM ASSEMBLY.
- REPEAT THIS STEP TWICE FOR BOTH SIDES OF STRUCTURE

BRACKET HOLES  
WILL FIT AROUND  
THREADED INSERTS

1202 (x4)  
TORX PAN HEAD  
1/4-20x3/4 ASSY

HAND TIGHTEN ONLY



BACK


FRONT

GABLE BEAM ASSEMBLY FROM  
STEPS 32 - 33

# STEP 34B - ROOF ASSEMBLY


Qty	PartNo	Description
8	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

**- REPEAT THIS STEP TWICE FOR BOTH SIDES OF STRUCTURE**



# STEP 35 - ROOF ASSEMBLY

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



**B12 GABLE BEAM ASSEMBLY - A4M03518**  
(x2) 88 13/16"x5 1/4"x1 7/16" (36x134x2255)

**J9 BEAM BRACKET - A4M03807**  
(x2) 1"x1 5/16"x4 9/16" (25x33.20x116)

**- REPEAT THIS STEP TWICE**

**BRACKET HOLES  
WILL FIT AROUND  
THREADED INSERTS**

**1202 (x2)  
TORX PAN HEAD  
1/4-20x3/4 ASSY**

**B12 (x1)  
GABLE BEAM ASSEMBLY**

**J9 (x1)  
BEAM BRACKET**


# STEP 36 - ROOF ASSEMBLY



Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

J8 GABLE BRACKET - A4M03804  
(x2) 4 13/16"x1 9/16"x1 9/16" (40x40x123)

**- REPEAT THIS STEP TWICE**






# STEP 37A - ROOF ASSEMBLY



GABLE BEAM ASSEMBLY FROM STEPS 35 - 36

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY


- WITH AT LEAST TWO ADDITIONAL PEOPLE, ATTACH GABLE BEAM ASSEMBLY.
- REPEAT THIS STEP TWICE FOR BOTH SIDES OF STRUCTURE



# STEP 37B - ROOF ASSEMBLY

Qty	PartNo	Description
8	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- REPEAT THIS STEP TWICE FOR BOTH SIDES OF STRUCTURE.




# STEP 38A - ROOF ASSEMBLY

Qty	PartNo	Description
40	H101132	TORX SOCKET SCREW SHORT 1/4-20



E03 PURLIN ASSEMBLY - A4M03651  
(x10) 89 15/16"x1 15/16"x1 9/16" (40x50x2284)


- ATTACH PURLINS.
- STARTING AT THE RIDGE AND WORKING DOWN WILL MAKE IT EASIER TO INSTALL PURLIN ASSEMBLIES.



# STEP 38B - ROOF ASSEMBLY

Qty	PartNo	Description
20	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- ONCE PURLINS HAVE BEEN INSTALLED,  
TIGHTEN ALL HARDWARE FROM PREVIOUS STEPS.



# STEP 39 - ROOF ASSEMBLY


Qty	PartNo	Description
10	H101117	SCREW WOODGRIP 10-16x3/4" BLK



A4M03528 STEEL SHEETING  
(x1)

- REMOVE PROTECTIVE FILM.
- SLIDE ROOF SHEET UP, MAKING SURE IT SLIDES UNDERNEATH THE RIDGE CAP.
- STARTING AT THE LEFT SIDE AND WORKING TO THE RIGHT, LINE UP THE HOLES IN THE ROOF SHEET WITH THE PILOT HOLES IN THE PURLINS.

- **WARNING: GLOVES ARE RECOMMENDED WHEN HANDLING STEEL ROOF PIECES.**



# STEP 40 - ROOF ASSEMBLY


Qty	PartNo	Description
10	H101117	SCREW WOODGRIP 10-16x3/4" BLK



A4M03528 STEEL SHEETING  
(x1)

- REMOVE PROTECTIVE FILM.
- SLIDE ROOF SHEET UP, MAKING SURE IT SLIDES UNDERNEATH THE RIDGE CAP.
- STARTING AT THE LEFT SIDE AND WORKING TO THE RIGHT, LINE UP THE HOLES IN THE ROOF SHEET WITH THE PILOT HOLES IN THE PURLINS.

**- WARNING: GLOVES ARE RECOMMENDED WHEN HANDLING STEEL ROOF PIECES.**




# STEP 41 - ROOF ASSEMBLY

Qty	PartNo	Description
30	H101117	SCREW WOODGRIP 10-16x3/4" BLK



A4M03528 STEEL SHEETING  
(x3)

- REMOVE PROTECTIVE FILM.
- INSTALL THREE SHEETS IN THE SAME WAY AS THE FIRST TWO.
- ATTACH AND FULLY TIGHTEN ALL SCREWS ON EACH ROOF SHEET BEFORE ATTACHING THE NEXT ONE. THIS MAKES IT POSSIBLE TO REACH ALL THE SCREWS WITHOUT GETTING ON THE ROOF.
- **WARNING: GLOVES ARE RECOMMENDED WHEN HANDLING STEEL ROOF PIECES.**




# STEP 42 - ROOF ASSEMBLY

Qty	PartNo	Description
8	H101116	SCREW SELF TAPPING 1/4x1 BLK



A4M03532 EDGE TRIM  
(x2)

- REMOVE PROTECTIVE FILM.
- SLIDE EDGE TRIM UNTIL ONE END IS POSITIONED UNDERNEATH RIDGE CAP AND OTHER END IS FLUSH WITH END.
- STARTING AT THE TOP, ALIGN SCREWS WITH SHEET SCREWS.
- **DUE TO MULTIPLE LAYERS OF METAL ON THE DRIP EDGE, IT IS RECOMMENDED THAT A 1/8" (3mm) DRILL BIT BE USED TO CREATE STARTER HOLES.**
- **WARNING: GLOVES ARE RECOMMENDED WHEN HANDLING STEEL ROOF PIECES.**






# STEP 43 - ROOF ASSEMBLY



A4M03653 DRIP TRIM  
(x1)

Qty	PartNo	Description
9	H101116	SCREW SELF TAPPING 1/4x1 BLK

- REMOVE PROTECTIVE FILM.
- ORIENT DRIP TRIM AS SHOWN BELOW.
- STARTING IN THE FRONT CORNER, ATTACH SCREWS SPACING EVERY OTHER RIB.
- **DUE TO MULTIPLE LAYERS OF METAL ON THE DRIP EDGE, IT IS RECOMMENDED THAT A 1/8" (3mm) DRILL BIT BE USED TO CREATE STARTER HOLES.**
- **WARNING: GLOVES ARE RECOMMENDED WHEN HANDLING STEEL ROOF PIECES.**




**REPEAT ROOF ASSEMBLY STEPS 39 - 43  
TO INSTALL SHEETMETAL ON OPPOSITE SIDE OF ROOF**

# STEP 44 - STRUCTURE ASSEMBLY





A4M01352 HOLE COVER  
(x70)

- USE A SMALL PIECE OF WOOD AND RUBBER Mallet TO TAP HOLE COVERS IN.
- DO NOT TAP DIRECTLY WITH A HAMMER AS YOU MAY DAMAGE THE POWDER COAT FINISH ON PRODUCT.



# STEP 45 - FRIDGE CABINET INSTALLATION


Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




S8 FRIDGE CABINET SIDE PANEL ASSEMBLY R - A4M03598  
(x1) 33 3/8"x23 3/8"x1 15/16" (50.00x594.00x848.20)

F4 FRIDGE CABINET FLOOR PANEL ASSEMBLY - A4M03595  
(x1) 28 1/8"x23 3/8"x2 5/8" (66x594x715)

- POSITION FLOOR PANEL IN THE PROXIMITY OF WHERE YOUR KITCHEN WILL BE.
- EACH FLOOR PANEL HAS FACTORY INSTALLED ADJUSTABLE FEET. USE PROVIDED HEX DRIVER TO ADJUST EACH FOOT UNTIL PANEL IS LEVEL.




# STEP 46 - FRIDGE CABINET INSTALLATION




Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

**S7 FRIDGE CABINET SIDE PANEL ASSEMBLY L - A4M03597**  
 (x1) 33 7/16"x23 3/8"x2 1/16" (53.00x594.00x849.70)




# STEP 47 - FRIDGE CABINET INSTALLATION




Qty	PartNo	Description
9	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

**G4 FRIDGE CABINET BACK PANEL ASSEMBLY - A4M03599**  
 (x1) 25 5/16"x33 3/8"x1 3/16" (30.00x847.20x643.00)




# STEP 48 - FRIDGE CABINET INSTALLATION




Qty	PartNo	Description
7	H101103	TORX SOCKET SCREW 1/4-20

T7 FRIDGE CABINET TABLETOP - A4M03641  
(x1) 27 3/8"x24 1/8"x1 1/4" (32x612x696)

- FLUSH BACK AND SIDES OF PANEL ASSEMBLY.
- SQUARE ALL SIDES OF CABINET BEFORE TIGHTENING HARDWARE.




# STEP 49 - FRIDGE CABINET INSTALLATION



FRIDGE CABINET FROM STEPS 45 - 48

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY


- POSITION FRIDGE CABINET ASSEMBLY UNDERNEATH LANCASTER L-SHAPE STRUCTURE.
- SIDE OF FRIDGE CABINET WILL SIT AGAINST THE INSIDE OF THE BACK RIGHT POST.
- BACKSIDE OF FRIDGE CABINET WILL SIT FLUSH WITH BACKSIDE OF POST.
- **BEFORE TIGHTENING HARDWARE, ADJUST CABINET FEET AS NEEDED UNTIL FRIDGE CABINET IS LEVEL.**





# STEP 50 - SINK CABINET ASSEMBLY


Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




S18 SINK CABINET SIDE PANEL ASSEMBLY L - A4M03705  
(x1) 33 3/8"x23 3/8"x2 1/2" (62.90x594.00x848.20)

F3 SINK CABINET FLOOR PANEL ASSEMBLY - A4M03560  
(x1) 37 3/16"x23 3/8"x2 5/8" (66x594x944)

- POSITION FLOOR PANEL IN THE PROXIMITY OF WHERE YOUR KITCHEN WILL BE.
- EACH FLOOR PANEL HAS FACTORY INSTALLED ADJUSTABLE FEET. USE PROVIDED HEX DRIVER TO ADJUST EACH FOOT UNTIL PANEL IS LEVEL.




# STEP 51 - SINK CABINET ASSEMBLY




Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

**S4 SINK CABINET SIDE PANEL ASSEMBLY R - A4M03563**  
 (x1) 33 3/8"x23 3/8"x2 5/8" (67.00x594.00x848.20)




# STEP 52 - SINK CABINET ASSEMBLY





Qty	PartNo	Description
9	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

G3 SINK CABINET BACK PANEL ASSEMBLY - A4M03564  
 (x1) 34 5/16"x33 3/8"x1 3/16" (30.00x847.20x872.00)

**G3 LABEL INDICATES  
 TOP OF BACK PANEL**



**1202 (x9)  
 TORX PAN HEAD  
 1/4-20x3/4 ASSY**



**G3 (x1)  
 SINK CABINET  
 BACK PANEL  
 ASSEMBLY**

**FRONT**

# STEP 53 - SINK CABINET ASSEMBLY



Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

S5 SINK CABINET SIDE PANEL ASSEMBLY M - A4M03567  
 (x1) 33 3/8"x23 3/8"x2 3/16" (56.20x593.00x847.00)

1202 (x2)  
 TORX PAN HEAD  
 1/4-20x3/4 ASSY


S5 LABEL INDICATES  
 TOP OF SIDE PANEL

FLUSH FRONT  
 SURFACE

S5 (x1)  
 SINK CABINET  
 SIDE PANEL  
 ASSEMBLY M

FRONT


# STEP 54 - SINK CABINET ASSEMBLY



Qty	PartNo	Description
16	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

H4 HORIZONTAL BEAM ASSEMBLY L - A4M03575  
(x4) 16 1/4"x3 3/8"x1" (25.00x85.00x413.00)

## - HARDWARE ATTACHES ON INSIDE OF CABINET




# STEP 55 - SINK CABINET ASSEMBLY




Qty	PartNo	Description
2	H101289	PAN HEAD SCREW 8-32x1/2" SS

**A2 MAGNET BRACKET - A4M03026**  
(x1) 1"x1 1/4"x3 1/8" (25x31x80)




# STEP 56 - SINK CABINET ASSEMBLY



Qty	PartNo	Description
9	H101103	TORX SOCKET SCREW 1/4-20

T4 SINK CABINET TABLETOP FRAME - A4M03566  
(x1) 37 3/16"x24 1/8"x1 1/4" (32x612x944)

- FLUSH BACK AND SIDE OF PANEL ASSEMBLY.
- SQUARE ALL SIDES OF CABINET BEFORE TIGHTENING HARDWARE.




## STEP 57 - SINK CABINET ASSEMBLY




SINK CABINET FROM  
STEPS 50 - 56

- POSITION SINK CABINET ASSEMBLY UNDERNEATH LANCASTER L-SHAPE STRUCTURE.
- DISTANCE BETWEEN FRIDGE CABINET WILL BE DETERMINED IN NEXT STEP.






# STEP 58 - GRILL CABINET ASSEMBLY




F2 GRILL CABINET FLOOR PANEL ASSEMBLY - A4M03048  
(x1) 2 5/8"x23 3/8"x38 1/4" (66x594x972)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- **LOOKING AT THE FRONT SIDE OF THE CABINETS, SLIDE FLOOR PANEL IN BETWEEN SINK AND FRIDGE CABINETS.**




## STEP 59 - GRILL CABINET ASSEMBLY

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- POSITION FLOOR PANEL AS SHOWN BELOW.
- EACH FLOOR PANEL HAS FACTORY INSTALLED ADJUSTABLE FEET. USE PROVIDED HEX DRIVER TO ADJUST EACH FOOT UNTIL PANEL IS LEVEL.
- ADJUST SINK AND FRIDGE CABINET TO ELIMINATE ANY GAPS BETWEEN FLOOR PANEL AND CABINETS.





# STEP 60 - GRILL CABINET ASSEMBLY



A6 ANGLED BRACKET - A4M03053  
(x1) 1 3/8"x1 15/16"x17 1/8" (35x50x435)

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




**MAKE SURE FRONT  
FACE OF FLOOR  
PANELS ARE FLUSH**

1202 (x4)  
TORX PAN HEAD 1/4-20x3/4 ASSY

A6 (x1)  
ANGLED BRACKET


# STEP 61 - GRILL CABINET ASSEMBLY



A6 ANGLED BRACKET - A4M03053  
(x1) 1 3/8"x1 15/16"x17 1/8" (35x50x435)

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




1202 (x4)  
TORX PAN HEAD 1/4-20x3/4 ASSY

A6 (x1)  
ANGLED BRACKET

**MAKE SURE FRONT  
FACE OF FLOOR  
PANELS ARE FLUSH**



# STEP 62 - GRILL CABINET ASSEMBLY




Qty	PartNo	Description
8	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

**G10 GRILL CABINET BACK PANEL ASSEMBLY - A4M03055**  
(x1) 1 3/16"x22 7/8"x38 3/16" (30x581x970)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 63 - GRILL CABINET ASSEMBLY




Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

S6 GRILL CABINET SIDE PANEL ASSEMBLY M - A4M03586  
 (x1) 23 3/8"x22 7/8"x1 3/8" (35.00x581.00x593.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 64A - GRILL CABINET ASSEMBLY




A5 SHELF BRACKET - A4M03141  
(x2) 5/8"x7/8"x2 1/16" (16x22x53)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- ATTACH SHELF BRACKETS ON BOTH SIDES OF CENTER GRILL CABINET.




# STEP 64B - GRILL CABINET ASSEMBLY



Qty	PartNo	Description
3	H101289	PAN HEAD SCREW 8-32x1/2" SS


L2 GRILL CABINET SHELF ASSEMBLY - A4M03589  
 (x1) 23 1/4"x18 3/8"x1" (25.00x467.00x591.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- PARTIALLY THREAD SCREWS INTO THREADED INSERTS.
- SET SHELF ONTO SCREWS AND THEN TIGHTEN HARDWARE TO FASTEN IN PLACE.




L2 (x1)  
GRILL CABINET  
SHELF ASSEMBLY

1289 (x1)  
PAN HEAD SCREW  
8-32x1/2" SS




L2 LABEL INDICATES  
FRONT OF SHELF

1289 (x2)  
PAN HEAD SCREW  
8-32x1/2" SS






# STEP 65 - GRILL CABINET ASSEMBLY




Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

**A9 HOSE BRACKET ASSEMBLY - A4M03060**  
**(x1) 1 1/4"x1 7/16"x2 9/16" (31.5x36.5x65)**

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 66 - GRILL CABINET ASSEMBLY



Qty	PartNo	Description
4	H101292	TORX PAN HEAD 1/4-20x13/32"



A13 GAS TANK HOLDER ASSEMBLY - A4M03047  
(x1) 1 15/16"x12 7/8"x14 3/4" (49x327x374)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.



A13 (x1)  
GAS TANK HOLDER  
ASSEMBLY


1292 (x4)  
TORX PAN  
HEAD  
1/4-20x13/32"



**NOTE ORIENTATION OF  
WING NUT TOWARDS FRONT**

# STEP 67 - GRILL CABINET ASSEMBLY

Qty	PartNo	Description
4	H101289	PAN HEAD SCREW 8-32x1/2" SS




**T2 GRILL TABLETOP ASSEMBLY - A4M03057**  
 (x1) 1 1/4"x23 3/8"x38 3/16" (32x594x970)




**A2 MAGNET BRACKET - A4M03026**  
 (x2) 1"x1 1/4"x3 1/8" (25x31x80)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.



**T2 (x1)**  
**GRILL TABLETOP ASSEMBLY**



**A2 (x2)**  
**MAGNET BRACKET**

**1289 (x4)**  
**PAN HEAD SCREW 8-32x1/2" SS**


# STEP 68A - GRILL CABINET ASSEMBLY



GRILL TABLETOP  
ASSEMBLY FROM STEP 67

Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY



- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- **HARDWARE ATTACHES ON INSIDE OF CABINET**



# STEP 68B - GRILL CABINET ASSEMBLY

Qty	PartNo	Description
4	H101103	TORX SOCKET SCREW 1/4-20

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




**TIGHTEN ALL HARDWARE**

1103 (x4)  
TORX SOCKET SCREW 1/4-20

**MAKE SURE FRONT  
FACE OF TABLETOP  
IS FLUSH WITH  
UPRIGHT PANEL**


# STEP 69 - GRILL CABINET ASSEMBLY



Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY


G11 GRILL VENTILATION PANEL - A4M03056  
(x1) 1 5/16"x11 3/16"x38 3/16" (33x284x970)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




1202 (x4)  
TORX PAN HEAD 1/4-20x3/4 ASSY

G11 (x1)  
GRILL VENTILATION PANEL




# STEP 70A - CORNER CABINET ASSEMBLY




F6 CORNER CABINET FLOOR PANEL ASSEMBLY - A4M03667  
(x1) 40 3/16"x23 7/16"x2 5/8" (66x595.50x1020)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- **LOOKING AT THE FRONT SIDE OF THE CABINETS, SLIDE FLOOR PANEL IN BETWEEN P03 POST AND SINK CABINET.**




# STEP 70B - CORNER CABINET ASSEMBLY

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- POSITION FLOOR PANEL AS SHOWN BELOW.
- EACH FLOOR PANEL HAS FACTORY INSTALLED ADJUSTABLE FEET. USE PROVIDED HEX DRIVER TO ADJUST EACH FOOT UNTIL PANEL IS LEVEL.
- ADJUST LEFT POST AND SINK CABINET TO ELIMINATE ANY GAPS BETWEEN FLOOR PANEL AND POST AND CABINETS.






# STEP 71 - CORNER CABINET ASSEMBLY



**A6 ANGLED BRACKET - A4M03053**  
 (x1) 1 3/8"x1 15/16"x17 1/8" (35x50x435)

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 72 - CORNER CABINET ASSEMBLY

Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY




H9 CORNER CABINET BRACKET ASSEMBLY - A4M03681  
(x1) 33 7/16"x4 3/4"x1 3/8" (35.00x120.00x848.70)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 73 - CORNER CABINET ASSEMBLY




Qty	PartNo	Description
9	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

**G9 CORNER CABINET BACK PANEL ASSEMBLY - A4M03669**  
(x1) 38 3/4"x33 7/16"x1 3/16" (30.00x848.70x984.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- **TIGHTEN ALL HARDWARE IN PREVIOUS STEP.**



# STEP 74 - CORNER CABINET ASSEMBLY




Qty	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

S15 CORNER CABINET SIDE PANEL ASSEMBLY M - A4M03675  
 (x1) 33 7/16"x23 3/8"x6 1/16" (154.10x593.00x848.70)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.


1202 (x3)  
 TORX PAN HEAD  
 1/4-20x3/4 ASSY

S15 LABEL INDICATES  
 TOP FRONT OF PANEL



S15 (x1)  
 CORNER CABINET  
 SIDE PANEL  
 ASSEMBLY M


# STEP 75 - CORNER CABINET ASSEMBLY




Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

H8 CORNER CABINET HORIZONTAL BEAM ASSEMBLY - A4M03672  
 (x1) 12 15/16"x3"x1" (25.00x76.50x328.80)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- **HARDWARE ATTACHES ON INSIDE OF CABINET**




# STEP 76 - CORNER CABINET ASSEMBLY



A5 SHELF BRACKET - A4M03141  
(x2) 5/8"x7/8"x2 1/16" (16x22x53)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- ATTACH SHELF BRACKETS ON SIDE OF CENTER GRILL CABINET.




# STEP 77 - CORNER CABINET ASSEMBLY




Qty	PartNo	Description
7	H101103	TORX SOCKET SCREW 1/4-20

S13 CONNECT PANEL ASSEMBLY - A4M03673  
 (x1) 35 1/8"x23 3/8"x2 3/8"x2 3/8" (61.00x594.00x892.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.



# STEP 78- CORNER CABINET ASSEMBLY




Qty	PartNo	Description
12	H101103	TORX SOCKET SCREW 1/4-20


T11 CORNER CABINET TOPTABLE ASSEMBLY - A4M03670  
 (x1) 40 3/16"x24 1/8"x1 1/4" (32.00x612.00x1020.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- SQUARE ALL SIDES OF CABINET BEFORE TIGHTENING HARDWARE.

1103 (x12)  
 TORX SOCKET  
 SCREW 1/4-20




FLUSH BACK AND  
 SIDE OF PANEL



T11 LABEL ON BOTTOM  
 SIDE INDICATES BACK

T11 (x1)  
 CORNER CABINET  
 TOPTABLE ASSEMBLY







# STEP 79- CORNER CABINET ASSEMBLY

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 80- CORNER CABINET ASSEMBLY




Qty	PartNo	Description
2	H101289	PAN HEAD SCREW 8-32x1/2" SS

A8 MAGNET BRACKET - A4M03715  
(x1) 3 1/8"x2 3/16"x1" (25.00x56.30x80.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 81 - CORNER CABINET ASSEMBLY




Qty	PartNo	Description
4	H101289	PAN HEAD SCREW 8-32x1/2" SS

A12 DOOR STOPPER - A4M04128  
(x1) 3 11/16"x1 3/4"x1/2" (13.30x45.00x94.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 82 - SINK CABINET FALSE PANEL ATTACHMENT




**D5 SINK CABINET TRIM PANEL ASSEMBLY - A4M03576**  
 (x1) 17 13/16"x10 1/4"x1" (26.00x260.00x452.00)


Qty	PartNo	Description
2	H101289	PAN HEAD SCREW 8-32x1/2" SS



**H2 STAINLESS STEEL HANDLE - A4M03024**  
 (x1) 5/8"x1 9/16"x11 13/16" (16x40x300)




# STEP 83 - SINK CABINET FALSE PANEL ATTACHMENT




FALSE PANEL ASSEMBLY  
FROM STEP 82

Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- **HARDWARE ATTACHES ON INSIDE OF CABINET.**




1202 (x4)  
TORX PAN HEAD  
1/4-20x3/4 ASSY




FALSE PANEL  
ASSEMBLY  
FROM STEP 82

**D5 LABEL INDICATES  
BOTTOM OF PANEL**




# STEP 84A - SINK INSTALLATION



A16 SINK ASSEMBLY - A4M03143  
(x1) 15 1/8"x15 5/16"x16 7/8" (384x389x429)


## 1. INSTALLING THE SINK DRAIN

- SET DRAIN INSIDE OF SINK BODY, PLACING FOAM GASKET BETWEEN SURFACES.
- FASTEN IN PLACE USING RUBBER GASKET AND DRAIN NUT FROM BOTTOM SIDE.




## 2. INSTALLING THE FAUCET

- INSTALL FAUCET BY PLACING HANDLE AND SPOUT INTO SINK OPENINGS AND SECURING IN PLACE VIA NUT.
- INSERT SCREWS TO LOCK.
- CONNECT WATER FAUCET LINES TOGETHER.




## 3. INSTALLING THE DRAIN FITTING

- ATTACH DRAIN FITTING TO SINK DRAIN.




# STEP 84B - SINK INSTALLATION



A16 SINK ASSEMBLY - A4M03143  
(x1) 15 1/8"x15 5/16"x16 7/8" (384x389x429)


## 4. INSTALLING THE OVERFLOW DRAIN

- MAKE SURE RUBBER GASKET IS INSTALLED IN OVERFLOW DRAIN.
- INSERT DRAIN SCREW TO HOLD IN PLACE.




## 5. INSTALLING THE OVERFLOW DRAIN

- ATTACH OVERFLOW DRAIN BY CONNECTING EACH END AS SHOWN.




## 6. INSTALLING THE MAIN DRAIN AND TRAP

- ATTACH TRAP AND CORRUGATED DRAIN HOSE TO DRAIN FITTING.



# STEP 84C - SINK INSTALLATION



A16 SINK ASSEMBLY - A4M03143  
(x1) 15 1/8"x15 5/16"x16 7/8" (384x389x429)



A4M03151 GARDEN HOSE ADAPTER  
(x1)

- DRAIN STRAINER MUST BE USED WHEN DISCARDING FOOD INSIDE OF SINK.
- DO NOT LET SOLID MATERIAL ENTER SINK BASIN.

## OPTIONS FOR WATER INLET SUPPLY HOOKUP:

- GARDEN HOSE ATTACHMENT USING PROVIDED ADAPTER
- WATER INLET SUPPLY LINE



## OPTIONS FOR DRAIN DISCHARGE:

- BUCKET OR GREY WATER CONTAINER
- FRENCH DRAIN OR DRY BASIN
- INTEGRATED SEWER SYSTEM
- CHECK YOUR LOCAL REQUIREMENTS.


**ATTACH ADAPTER  
TO INLET LINE AND  
TIGHTEN WITH WRENCH**

3151 (x1)  
GARDEN HOSE  
ADAPTER

**IT IS RECOMMENDED TO  
APPLY A FINE BEAD OF  
SILICONE, TO UNDERNEATH  
SIDE OF ALL SINK FLANGES  
BEFORE INSTALLING**




A16 (x1)  
SINK ASSEMBLY






# STEP 85A - FRIDGE CABINET MARBLE INSTALLATION



M3 FRIDGE CABINET MARBLE - A4M03602  
(x1) 28 1/8"x24 15/16"x1 15/16" (50x634x715)


- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- IT IS RECOMMENDED TO HAVE AT LEAST TWO PEOPLE SET MARBLE COUNTERTOP IN PLACE.
- SLIDE IN PLACE UNTIL MARBLE IS TIGHT AGAINST POST AND SIDES ARE FLUSH WITH PANEL.
- **WHEN SETTING MARBLE IN PLACE, MAKE SURE YOUR FINGERS ARE CLEAR AND NOT UNDERNEATH MARBLE.**




# STEP 85B- FRIDGE CABINET MARBLE INSTALLATION

Qty	PartNo	Description
4	H101053	STEEL WASHER 6x20
4	H101054	SEALANT WASHER
4	H101292	TORX PAN HEAD 1/4-20x13/32"

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- MAKE SURE YOU ARE USING THE CORRECT HARDWARE FOR THIS STEP.
- ONCE MARBLE IS IN PLACE, IT IS RECOMMENDED TO COVER WITH A PIECE OF CARDBOARD OR FOAM UNTIL ASSEMBLY IS FINISHED TO PREVENT DAMAGE.
- DO NOT USE MARBLE SURFACE AS A WORK BENCH.




# STEP 86A- SINK CABINET MARBLE INSTALLATION



M7 SINK CABINET MARBLE - A4M03655  
(x1) 37 3/16"x24 15/16"x1 15/16" (50x634x944)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- IT IS RECOMMENDED TO HAVE AT LEAST TWO PEOPLE SET MARBLE COUNTERTOP IN PLACE.
- SLIDE IN PLACE UNTIL MARBLE IS TIGHT AGAINST PANEL AND SIDES ARE FLUSH WITH PANEL.
- **WHEN SETTING MARBLE IN PLACE, MAKE SURE YOUR FINGERS ARE CLEAR AND NOT UNDERNEATH MARBLE.**



# STEP 86B - SINK CABINET MARBLE INSTALLATION

Qty	PartNo	Description
4	H101053	STEEL WASHER 6x20
4	H101054	SEALANT WASHER
4	H101292	TORX PAN HEAD 1/4-20x13/32"



- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- IT IS RECOMMENDED TO USE THE 6" MAGNETIC DRIVER EXTENSION PROVIDED IN YOUR HARDWARE KIT FOR THIS STEP
- MAKE SURE YOU ARE USING THE CORRECT HARDWARE FOR THIS STEP.
- ONCE MARBLE IS IN PLACE, IT IS RECOMMENDED TO COVER WITH A PIECE OF CARDBOARD OR FOAM UNTIL ASSEMBLY IS FINISHED TO PREVENT DAMAGE.
- DO NOT USE MARBLE SURFACE AS A WORK BENCH.

1054 (x4)  
SEALANT WASHER


1053 (x4)  
STEEL WASHER 6x20

1292 (x4)  
TORX PAN HEAD 1/4-20x13/32"


**DO NOT OVERTIGHTEN HARDWARE**




# STEP 87 - SINK CABINET MARBLE INSTALLATION



M5 SINK COVER MARBLE - A4M03147  
(x1) 11/16"x14 3/4"x16 5/16" (18x375x415)




## STEP 88A - CORNER CABINET MARBLE INSTALLATION



M9 CORNER CABINET MARBLE - A4M03671  
(x1) 40 3/16"x24 15/16"x1 15/16" (50x634x1020)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- IT IS RECOMMENDED TO HAVE AT LEAST TWO PEOPLE SET MARBLE COUNTERTOP IN PLACE.
- SLIDE IN PLACE UNTIL MARBLE IS TIGHT AGAINST POST AND SIDES ARE FLUSH WITH PANEL.
- **WHEN SETTING MARBLE IN PLACE, MAKE SURE YOUR FINGERS ARE CLEAR AND NOT UNDERNEATH MARBLE.**



# STEP 88B - CORNER CABINET MARBLE INSTALLATION


Qty	PartNo	Description
4	H101053	STEEL WASHER 6x20
4	H101054	SEALANT WASHER
4	H101292	TORX PAN HEAD 1/4-20x13/32"

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.


- MAKE SURE YOU ARE USING THE CORRECT HARDWARE FOR THIS STEP.

- ONCE MARBLE IS IN PLACE, IT IS RECOMMENDED TO COVER WITH A PIECE OF CARDBOARD OR FOAM UNTIL ASSEMBLY IS FINISHED TO PREVENT DAMAGE.

- DO NOT USE MARBLE SURFACE AS A WORK BENCH.



# STEP 89A - SPICE BASKET DRAWER INSTALLATION




**D16 SPICE BASKET - A4M03683**  
(x1) 33 3/16"x79.80x13 3/4" (348.90x481.00x843.20)




**A4 SLIDE BRACKET ASSEMBLY - A4M03709**  
(x2) 18 7/8"x3 1/8"x1 1/16" (27.20x80.00x480.00)

- ATTACH A4 TO SPICE BASKET.






# STEP 89B - SPICE BASKET DRAWER INSTALLATION



Qty	PartNo	Description
12	H101289	PAN HEAD SCREW 8-32x1/2" SS

A7 TRIANGLE BRACKET - A4M03708  
(x2) 5 7/8"x5 7/8"x9/16" (15.00x150.00x150.00)

- IT IS RECOMMENDED TO USE THE 6" MAGNETIC DRIVER EXTENSION PROVIDED IN YOUR HARDWARE KIT FOR THIS STEP




# STEP 89C - SPICE BASKET DRAWER INSTALLATION

Qty	PartNo	Description
2	H101307	SHOULDER BOLT 8-32x30mm SS



H2 STAINLESS STEEL HANDLE - A4M03024  
(x1) 5/8"x1 9/16"x11 13/16" (16x40x300)




# STEP 90A - SPICE BASKET DRAWER INSTALLATION




SPICE BASKET DRAWER  
ASSEMBLY STEPS 89A-89C

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- ATTACH SPICE BASKET DRAWER ASSEMBLY BY ALIGNING BOTH ENDS OF FACTORY ASSEMBLED DRAWER SLIDES WITH ONE ANOTHER.
- PRESS TOGETHER UNTIL DRAWER SLIDES CONNECT.



SPICE BASKET  
DRAWER ASSEMBLY

SLIDE INNER RACE  
OF DRAWER SLIDE OUT  
BEFORE ATTACHING SLIDES




ALIGN DRAWER SLIDES  
ON BOTH SIDES OF TRASH  
CAN HOLDER

# STEP 90B - SPICE BASKET DRAWER INSTALLATION

Qty	PartNo	Description
11	H101289	PAN HEAD SCREW 8-32x1/2" SS

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- IT IS RECOMMENDED TO USE THE 6" MAGNETIC DRIVER EXTENSION PROVIDED IN YOUR HARDWARE KIT FOR THIS STEP.
- ADJUST SLIDE BRACKETES TO LINE UP THE HOLES.
- **LEFT HARDWARE ATTACHES ON INSIDE OF CABINET**



# STEP 91 - COENER CABINET SHEFT ASSEMBLY




Qty	PartNo	Description
2	H101289	PAN HEAD SCREW 8-32x1/2" SS

L6 CORNER CABINET SHEFT ASSEMBLY - A4M03680  
 (x1) 25 5/8"x23 3/16"x1" (25.00x589.00x650.40)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- PARTIALLY THREAD A SCREW TO THREADED INSERT ON SIDE OF BACK PANEL.
- SET SHELF ONTO SCREW AND THEN TIGHTEN ALL HARDWARE TO FASTEN IN PLACE.


1289 (x1)  
 PAN HEAD SCREW  
 8-32x1/2" SS

L6 LABEL INDICATES  
 BACK OF SHELF



L6 (x1)  
 CORNER CABINET  
 SHEFT ASSEMBLY

1289 (x1)  
 PAN HEAD SCREW  
 8-32x1/2" SS




# STEP 92 - PIZZA OVEN CABINET ASSEMBLY

Qty	PartNo	Description
6	H101309	PAN HEAD SCREW 8-32x2.5" SS




**H10 PIZZA OVEN CABINET HINGE CHANNEL ASSEMBLY - A4M03686**  
 (x1) 26 9/16"x2 15/16"x2 1/8" (54.00x74.80x674.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 93A - PIZZA OVEN CABINET ASSEMBLY




F1 PIZZA OVEN CABINET FLOOR PANEL ASSEMBLY - A4M03538  
(x1) 40 3/16"x23 3/8"x2 5/8" (66x594x1020)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- **LOOKING AT THE FRONT SIDE OF THE CABINETS, SLIDE FLOOR PANEL IN BETWEEN P01 POST AND STORAGE CABINET.**




# STEP 93B - PIZZA OVEN CABINET ASSEMBLY

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- POSITION FLOOR PANEL AS SHOWN BELOW.
- EACH FLOOR PANEL HAS FACTORY INSTALLED ADJUSTABLE FEET. USE PROVIDED HEX DRIVER TO ADJUST EACH FOOT UNTIL PANEL IS LEVEL.
- ADJUST LEFT POST AND RIGHT CORNER CABINET TO ELIMINATE ANY GAPS BETWEEN FLOOR PANEL AND POST AND CABINETS.






# STEP 94 - PIZZA OVEN CABINET ASSEMBLY



Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

A6 ANGLED BRACKET - A4M03053  
(x1) 1 3/8"x1 15/16"x17 1/8" (35x50x435)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.



1202 (x4)  
TORX PAN HEAD  
1/4-20x3/4 ASSY

A6 (x1)  
ANGLED BRACKET

**MAKE SURE FRONT  
FACE OF FLOOR  
PANELS ARE FLUSH**


# STEP 95 - PIZZA OVEN CABINET ASSEMBLY




Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

S14 PIZZA OVEN CABINET SIDE PANEL ASSEMBLY - A4M03657  
 (x1) 26 9/16"x23 3/8"x1 3/8" (35.00x594.00x675.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 96 - PIZZA OVEN CABINET ASSEMBLY



Qty	PartNo	Description
12	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

G8 PIZZA OVEN CABINET BACK PANEL ASSEMBLY - A4M03658  
 (x1) 38 3/4"x26 1/2"x1 3/16" (30.00x673.50x984.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 97- PIZZA OVEN CABINET ASSEMBLY




Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

S2 PIZZA OVEN CABINET SIDE PANEL ASSEMBLY M - A4M03545  
(x1) 26 1/2"x23 3/8"x1 3/8" (35.00x593.00x673.50)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 98 - PIZZA OVEN CABINET ASSEMBLY



**A5 SHELF BRACKET - A4M03141**  
(x2) 5/8"x7/8"x2 1/16" (16x22x53)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- ATTACH SHELF BRACKETS ON BOTH SIDES OF CENTER GRILL CABINET.




# STEP 99 - PIZZA OVEN CABINET ASSEMBLY




Qty	PartNo	Description
3	H101289	PAN HEAD SCREW 8-32x1/2" SS

L5 PIZZA OVEN CABINET SHEFT - A4M03661  
 (x1) 23 1/4"x19 1/4"x1" (25.00x489.50x591.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- PARTIALLY THREAD SCREWS INTO THREADED INSERTS.
- SET SHELF ONTO SCREWS AND THEN TIGHTEN HARDWARE TO FASTEN IN PLACE.




# STEP 100 - PIZZA OVEN CABINET ASSEMBLY




Qty	PartNo	Description
2	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

**A9 HOSE BRACKET ASSEMBLY - A4M03060**  
(x1) 1 1/4"x1 7/16"x2 9/16" (31.5x36.5x65)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 101 - PIZZA OVEN CABINET ASSEMBLY



Qty	PartNo	Description
4	H101292	TORX PAN HEAD 1/4-20x13/32"

A13 GAS TANK HOLDER ASSEMBLY - A4M03047  
(x1) 1 15/16"x12 7/8"x14 3/4" (49x327x374)


- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.






# STEP 102 - PIZZA OVEN CABINET ASSEMBLY

Qty	PartNo	Description
4	H101289	PAN HEAD SCREW 8-32x1/2" SS




**T1 PIZZA OVEN CABINET TABLETOP ASSEMBLY - A4M03543**  
(x1) 40 3/16"x23 3/8"x1 1/4" (32x594x1020)

**A2 MAGNET BRACKET - A4M03026**  
(x2) 1"x1 1/4"x3 1/8" (25x31x80)




# STEP 103A - PIZZA OVEN CABINET ASSEMBLY



Qty	PartNo	Description
3	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

**PIZZA OVEN TABLETOP  
ASSEMBLY FROM STEP 102**


- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- **HARDWARE ATTACHES ON INSIDE OF CABINET**




# STEP 103B - PIZZA OVEN CABINET ASSEMBLY

Qty	PartNo	Description
7	H101103	TORX SOCKET SCREW 1/4-20

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 104 - PIZZA OVEN CABINET ASSEMBLY




Qty	PartNo	Description
5	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

T10 PIZZA OVEN CABINET MARBLE PANEL ASSEMBLY L - A4M03662  
 (x1) 24 1/8"x4 5/16"x6 3/4" (172.20x109.00x612.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 105 - PIZZA OVEN CABINET ASSEMBLY




Qty	PartNo	Description
6	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

T3 PIZZA OVEN CABINET MARBLE PANEL ASSEMBLY R - A4M03551  
 (x1) 612.00x4 5/16"x6 3/4" (172.20x109.00x612.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.




# STEP 106 - PIZZA OVEN CABINET ASSEMBLY




Qty	PartNo	Description
4	H101202	TORX PAN HEAD 1/4-20x3/4 ASSY

O8 PIZZA OVEN VENTILATION PANEL - A4M03078  
(x1) 1 3/16"x3 3/4"x31 7/16" (30x95x799)


- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.



# STEP 107A - PIZZA OVEN CABINET ASSEMBLY




M1 PIZZA OVEN CABINET MARBLE - A4M03553  
(x1) 24 13/16"x4 5/16"x1 15/16" (50.00x109.00x630.00)



M8 PIZZA OVEN CABINET MARBLE R - A4M03666  
(x1) 24 15/16"x4 5/16"x1 15/16" (50.00x109.00x634.00)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- IT IS RECOMMENDED TO HAVE AT LEAST TWO PEOPLE SET MARBLE COUNTERTOP IN PLACE.
- SLIDE IN PLACE UNTIL MARBLE IS TIGHT AGAINST POST AND SIDES ARE FLUSH WITH PANEL.
- **WHEN SETTING MARBLE IN PLACE, MAKE SURE YOUR FINGERS ARE CLEAR AND NOT UNDERNEATH MARBLE.**



# STEP 107B - PIZZA OVEN CABINET ASSEMBLY


Qty	PartNo	Description
4	H101053	STEEL WASHER 6x20
4	H101054	SEALANT WASHER
4	H101292	TORX PAN HEAD 1/4-20x13/32"

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.

- MAKE SURE YOU ARE USING THE CORRECT HARDWARE FOR THIS STEP.

- ONCE MARBLE IS IN PLACE, IT IS RECOMMENDED TO COVER WITH A PIECE OF CARDBOARD OR FOAM UNTIL ASSEMBLY IS FINISHED TO PREVENT DAMAGE.

- DO NOT USE MARBLE SURFACE AS A WORK BENCH.






# STEP 108 - CORNER CABINET DOOR INSTALLATION



D17 CORNER CABINET DOOR ASSEMBLY - A4M03682  
(x1) 33 7/8"x18 1/4"x15/16" (23.20x463x860.40)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- INSERT HINGE PIN ON BOTTOM DOOR INTO THE HOLE ON FLOOR PANEL.
- PRESS DOWN HINGE PIN ON TOP DOOR INTO THE HOLE ON TOPTABLE ASSEMBLY.



# STEP 109A - KITCHEN TRASH CAN INSTALLATION




Qty	PartNo	Description
6	H101289	PAN HEAD SCREW 8-32x1/2" SS


**H3 TRASH CAN BRACKET ASSEMBLY - A4M03610**  
 (x1) 1 3/8"x18 1/16"x15 13/16" (35.00x401.60x458.00)

**A11 TRIANGLE PANEL - A4M03086**  
 (x2) 13/16"x13 3/4"x13 3/4" (20x350x350)

**- IT IS RECOMMENDED TO USE THE 6" MAGNETIC DRIVER EXTENSION PROVIDED IN YOUR HARDWARE KIT FOR THIS STEP**




# STEP 109B - KITCHEN TRASH CAN INSTALLATION




Qty	PartNo	Description
9	H101289	PAN HEAD SCREW 8-32x1/2" SS

D9 TRASH CAN PANEL ASSEMBLY - A4M03608  
(x1) 22 1/4"x17 3/4"x15/16" (24.00x451.00x565.00)

- IT IS RECOMMENDED TO USE THE 6" MAGNETIC DRIVER EXTENSION PROVIDED IN YOUR HARDWARE KIT FOR THIS STEP




# STEP 109C - KITCHEN TRASH CAN INSTALLATION



Qty	PartNo	Description
2	H101307	SHOULDER BOLT 8-32x30mm SS

H2 STAINLESS STEEL HANDLE - A4M03024  
(x1) 5/8"x1 9/16"x11 13/16" (16x40x300)




# STEP 110 - KITCHEN TRASH CAN INSTALLATION




TRASH CAN ASSEMBLY  
STEPS 109A - 109C

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- ATTACH TRASH CAN ASSEMBLY BY ALIGNING BOTH ENDS OF FACTORY ASSEMBLED DRAWER SLIDES WITH ONE ANOTHER.
- PRESS TOGETHER UNTIL DRAWER SLIDES CONNECT.




SLIDE INNER RACE  
OF DRAWER SLIDE OUT  
BEFORE ATTACHING SLIDES




ALIGN DRAWER SLIDES  
ON BOTH SIDES OF TRASH  
CAN HOLDER

# STEP 111A - KITCHEN DRAWER ASSEMBLY

Qty	PartNo	Description
9	H101289	PAN HEAD SCREW 8-32x1/2" SS




**D4 SINK CABINET DRAWER BODY ASSEMBLY - A4M03571**  
(x1) 22 1/4"x16 1/16"x6 7/16" (164.20x408.40x565.40)




**D3 SINK CABINET DRAWER PANEL ASSEMBLY - A4M03569**  
(x1) 17 3/4"x10 1/4"x15/16" (24x260x451)

- ALIGN SCREWS WITH PILOT HOLES.




# STEP 111B - KITCHEN DRAWER ASSEMBLY




Qty	PartNo	Description
2	H101307	SHOULDER BOLT 8-32x30mm SS

H2 STAINLESS STEEL HANDLE - A4M03024  
(x1) 5/8"x1 9/16"x11 13/16" (16x40x300)

- INSTALL DRAWER HANDLE TO DRAWER.




# STEP 111C - KITCHEN DRAWER ASSEMBLY




**DRAWER ASSEMBLY  
STEPS 111A - 111B**

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- ATTACH DRAWER ASSEMBLY BY ALIGNING BOTH ENDS OF FACTORY ASSEMBLED DRAWER SLIDES WITH ONE ANOTHER.
- PRESS TOGETHER UNTIL DRAWER SLIDES CONNECT.



**SLIDE INNER RACE  
OF DRAWER SLIDE OUT  
BEFORE ATTACHING SLIDES**



**ALIGN DRAWER SLIDES  
ON BOTH SIDES OF  
DRAWER HOLDER**



# STEP 112A - DOOR ASSEMBLY


Qty	PartNo	Description
20	H101185	PHILLIPS FLAT HEAD 8-32x.5 SCREW



**D14 PIZZA OVEN CABINET DOOR ASSEMBLY L - A4M03659**  
(x1) 28 7/16"x18 7/8"x15/16" (24.00x480.00x722.50)



**D15 PIZZA OVEN CABINET DOOR ASSEMBLY - A4M03664**  
(x1) 28 7/16"x18 7/8"x15/16" (24.00x480.00x722.50)




**D6 SINK CABINET DOOR ASSEMBLY L - A4M03577**  
(x1) 22 1/4"x17 13/16"x15/16" (24x452x565)



**D7 GRILL CABINET DOOR ASSEMBLY L - A4M03587**  
(x1) 24 13/16"x19 1/16"x15/16" (24x484.15x630)




**D8 GRILL CABINET DOOR ASSEMBLY R - A4M03590**  
(x1) 24 13/16"x19 1/16"x15/16" (24x484.15x630)




**A4M03025 FULL OVERLAY HINGE**  
(x10)

- INSTALL CABINET HINGES TO ALL DOORS.

**DO NOT OVERTIGHTEN HARDWARE.**




# STEP 112B - DOOR ASSEMBLY



H2 STAINLESS STEEL HANDLE - A4M03024  
(x5) 5/8"x1 9/16"x11 13/16" (16x40x300)

Qty	PartNo	Description
10	H101307	SHOULDER BOLT 8-32x30mm SS

- INSTALL CABINET HANDLES TO ALL DOORS.
- REPEAT THIS STEP 5 TIMES.




# STEP 113 - CABINET DOOR ATTACHMENT



Qty	PartNo	Description
8	H101185	PHILLIPS FLAT HEAD 8-32x.5 SCREW

D14 PIZZA OVEN CABINET DOOR ASSEMBLY L - A4M03659  
(x1) 28 7/16"x18 7/8"x15/16" (24.00x480.00x722.50)

- ONLY KITCHEN CABINETS ARE SHOWN
- FOR THIS STEP IT IS HELPFUL TO HAVE AN ADDITIONAL PERSON HELP HOLD DOOR IN PLACE.
- WITH CABINET HINGES ATTACHED TO DOOR, ALIGN HOLES IN HINGE BRACKET WITH THREADED INSERTS IN SIDE OF CABINET PANEL.



D14 (x1)  
PIZZA OVEN  
CABINET DOOR  
ASSEMBLY L

**ALIGN HINGE BRACKET WITH  
THREADED INSERTS IN PANEL**

**DO NOT OVERTIGHTEN HARDWARE**

1185 (x8)  
SCREW - 1/2"


# STEP 114 - CABINET DOOR ATTACHMENT



Qty	PartNo	Description
8	H101185	PHILLIPS FLAT HEAD 8-32x.5 SCREW

**D15 PIZZA OVEN CABINET DOOR ASSEMBLY - A4M03664**  
(x1) 28 7/16"x18 7/8"x15/16" (24.00x480.00x722.50)

- ONLY KITCHEN CABINETS ARE SHOWN
- FOR THIS STEP IT IS HELPFUL TO HAVE AN ADDITIONAL PERSON HELP HOLD DOOR IN PLACE.
- WITH CABINET HINGES ATTACHED TO DOOR, ALIGN HOLES IN HINGE BRACKET WITH THREADED INSERTS IN SIDE OF CABINET PANEL.



**D15 (x1)**  
**PIZZA OVEN CABINET**  
**DOOR ASSEMBLY**

**ALIGN HINGE BRACKET WITH**  
**THREADED INSERTS IN PANEL**

**DO NOT OVERTIGHTEN**  
**HARDWARE**

**1185 (x8)**  
**SCREW - 1/2"**


# STEP 115 - CABINET DOOR ATTACHMENT




Qty	PartNo	Description
8	H101185	PHILLIPS FLAT HEAD 8-32x.5 SCREW

D6 SINK CABINET DOOR ASSEMBLY L - A4M03577  
(x1) 22 1/4"x17 13/16"x15/16" (24x452x565)

- ONLY KITCHEN CABINETS ARE SHOWN
- FOR THIS STEP IT IS HELPFUL TO HAVE AN ADDITIONAL PERSON HELP HOLD DOOR IN PLACE.
- WITH CABINET HINGES ATTACHED TO DOOR, ALIGN HOLES IN HINGE BRACKET WITH THREADED INSERTS IN SIDE OF CABINET PANEL.



D6 (x1)  
SINK CABINET  
DOOR ASSEMBLY L



**ALIGN HINGE BRACKET WITH  
THREADED INSERTS IN PANEL**

**DO NOT OVERTIGHTEN HARDWARE**

1185 (x8)  
SCREW - 1/2"


# STEP 116 - CABINET DOOR ATTACHMENT




Qty	PartNo	Description
8	H101185	PHILLIPS FLAT HEAD 8-32x.5 SCREW

D7 GRILL CABINET DOOR ASSEMBLY L - A4M03587  
(x1) 24 13/16"x19 1/16"x15/16" (24x484.15x630)

- ONLY KITCHEN CABINETS ARE SHOWN
- FOR THIS STEP IT IS HELPFUL TO HAVE AN ADDITIONAL PERSON HELP HOLD DOOR IN PLACE.
- WITH CABINET HINGES ATTACHED TO DOOR, ALIGN HOLES IN HINGE BRACKET WITH THREADED INSERTS IN SIDE OF CABINET PANEL.



D7 (x1)  
GRILL CABINET  
DOOR  
ASSEMBLY L



**ALIGN HINGE BRACKET WITH  
THREADED INSERTS IN PANEL**

**DO NOT OVERTIGHTEN HARDWARE**

1185 (x8)  
SCREW - 1/2"


# STEP 117 - CABINET DOOR ATTACHMENT



Qty	PartNo	Description
8	H101185	PHILLIPS FLAT HEAD 8-32x.5 SCREW

D8 GRILL CABINET DOOR ASSEMBLY R - A4M03590  
(x1) 24 13/16"x19 1/16"x15/16" (24x484.15x630)


- ONLY KITCHEN CABINETS ARE SHOWN
- FOR THIS STEP IT IS HELPFUL TO HAVE AN ADDITIONAL PERSON HELP HOLD DOOR IN PLACE.
- WITH CABINET HINGES ATTACHED TO DOOR, ALIGN HOLES IN HINGE BRACKET WITH THREADED INSERTS IN SIDE OF CABINET PANEL.



**ALIGN HINGE BRACKET WITH  
THREADED INSERTS IN PANEL**

**DO NOT OVERTIGHTEN  
HARDWARE**

**1185 (x8)  
SCREW - 1/2"**





**D8 (x1)  
GRILL  
CABINET  
DOOR  
ASSEMBLY R**


# STEP 118 - CABINET DOOR ADJUSTMENT (AS NEEDED)

- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- ADJUST HINGES (AS NEEDED) SO THAT THE GAP AROUND ALL DOORS IS THE SAME AND THERE IS NO INTERFERENCE BETWEEN DOORS AND CABINETS.
- ADJUST MAGNET CATCH BRACKETS AS NEEDED.

**LOOSEN SCREWS TO ADJUST  
MAGNET BRACKET, UNTIL IT  
COMES IN CONTACT WITH  
DOOR IN THE SHUT POSITION**




**SCREW #1:  
SCREW CLOCKWISE TO BRING  
EDGE OF DOOR AWAY FROM  
CABINET. SCREW COUNTER  
CLOCKWISE TO BRING EDGE OF  
DOOR CLOSER TO CABINET**



**SCREW #2:  
LOOSEN THESE SCREWS TO  
SLIDE DOOR TOWARD CABINET  
OR AWAY FROM CABINET**




## STEP 119 - KITCHEN ACCESSORY



A4M02290 MAGNETIC PAPER TOWEL HOLDER  
(x2)


- ONLY KITCHEN CABINETS ARE SHOWN FOR DETAIL.
- MAGNETIC PAPER TOWEL HOLDER CAN BE ATTACHED TO ANY METAL SURFACE ON KITCHEN.
- WE RECOMMEND ATTACHING TO THE INSIDE OF GRILL CABINET DOOR.
- **MAKE SURE TO KEEP PAPER TOWEL HOLDER AT A SAFE DISTANCE FROM GRILLING SURFACE.**




## STEP 120 - KITCHEN ANCHORING

Qty	PartNo	Description
8	H100630	WASHER FLAT 8x19 BLK
8	H100120	CONCRETE ANCHOR 1/4"x2"

- MANUFACTURER RECOMMENDS INSTALLATION ON CONCRETE SURFACE OR CONCRETE POST PADS AS SHOWN BELOW.
- FOR INSTALLATION ON WOOD DECK, YOU MUST ENSURE THERE IS AMPLE STRUCTURAL SUPPORT UNDER THE DECK. HARDWARE NOT INCLUDED FOR DECK ATTACHMENT.




# OUTDOOR KITCHEN GRILL KIT




9240025 OUTDOOR KITCHEN GRILL KIT  
(x1)

- FOR INSTALLATION AND DETAILED INFORMATION OF OUTDOOR KITCHEN GRILL KIT, REFER TO ASSEMBLY INSTRUCTIONS THAT COME PACKAGED WITH THE OUTDOOR KITCHEN GRILL KIT.
- FOLLOW DIRECTIONS FOR PROPER CARE AND USE.




**NATURAL GAS CONVERSION KIT AVAILABLE BY CONTACTING BACKYARD DISCOVERY AT  
[www.backyarddiscovery.com](http://www.backyarddiscovery.com) 1-800-856-4445**

# OUTDOOR KITCHEN PIZZA OVEN



9240018 OUTDOOR KITCHEN PIZZA OVEN  
(x1)

- FOR INSTALLATION AND DETAILED INFORMATION OF OUTDOOR KITCHEN PIZZA OVEN, REFER TO ASSEMBLY INSTRUCTIONS THAT COME PACKAGED WITH THE OUTDOOR KITCHEN PIZZA OVEN.
- FOLLOW DIRECTIONS FOR PROPER CARE AND USE.




**NATURAL GAS CONVERSION KIT AVAILABLE BY CONTACTING BACKYARD DISCOVERY AT  
[www.backyarddiscovery.com](http://www.backyarddiscovery.com) 1-800-856-4445**

# OUTDOOR KITCHEN FRIDGE



9240162 OUTDOOR KITCHEN FRIDGE - RIGHT OPEN  
(x1)




- FOR INSTALLATION OF OUTDOOR KITCHEN FRIDGE, REFER TO PAGES IN THIS INSTRUCTION MANUAL.
- FOR DETAILED INFORMATION OF OUTDOOR KITCHEN FRIDGE, REFER TO ASSEMBLY INSTRUCTIONS THAT COME PACKAGED WITH THE OUTDOOR KITCHEN FRIDGE.
- FOLLOW DIRECTIONS FOR PROPER CARE AND USE.



# OUTDOOR KITCHEN FRIDGE



- CAREFULLY SLIDE FRIDGE INTO CABINET OPENING MAKING SURE THAT THE ELECTRICAL CORD IS ROUTED THROUGH THE HOLES IN THE SIDE PANELS OF THE CABINET.


- IF FRIDGE IS NOT IN UPRIGHT POSITION, PLEASE LET SIT FOR 24 HRS BEFORE PLUGGING INTO RECEPTACLE.
- FRIDGE CANNOT BE CONNECTED TO ELECTRICAL ENCLOSURE ATTACHED TO OUTDOOR STRUCTURE.



# OUTDOOR KITCHEN FRIDGE

- ALIGN FEET ON FRIDGE UNIT SO THAT IT IS LEVEL AND DOES NOT TILT.
- TURN FEET CLOCKWISE TO EXTEND THEM AND COUNTERCLOCKWISE TO SHORTEN. REPEAT THIS FOR ALL FOUR FRIDGE FEET AS NEEDED TO LEVEL.





**9205413** | **ELECTRICAL ENCLOSURE**  
*(x1)*

FOR POWERPORT INSTALLATION REFER TO ASSEMBLY INSTRUCTIONS THAT COME PACKAGED WITH THE POWERPORT KIT. INSTALL ON ANY EXTERIOR POST THAT IS DESIRED. FOLLOW DIRECTIONS FOR PROPER INSTALLATION.